



WC45i-GW-485 Modbus Gateway

User & Reference Manual



Safety Information

The products described in this manual can fail in a variety of modes due to misuse, age, or malfunction and is not designed or intended for used in systems requiring fail-safe performance, including life safety systems. Systems with the products must be designed to prevent personal injury and property damage during product operation and in the event of product failure.



Warning! Remove power before connecting or disconnecting the interface or RF cables.

FreeWave Technologies, Inc. warrants the FreeWave® WC45i-GW-485 Modbus Gateway (Product) that you have purchased against defects in materials and manufacturing for a period of three years from the date of shipment, depending on model number. In the event of a Product failure due to materials or workmanship, FreeWave will, at its discretion, repair or replace the Product. For evaluation of Warranty coverage, return the Product to FreeWave upon receiving a Return Material Authorization (RMA). The replacement product will remain under warranty for 90 days or the remainder of the original product warranty period, whichever is longer.

IN NO EVENT WILL FREEWAVE TECHNOLOGIES, INC., ITS SUPPLIERS, OR ITS LICENSORS BE LIABLE FOR ANY DAMAGES ARISING FROM THE USE OF OR INABILITY TO USE THIS PRODUCT. THIS INCLUDES BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, INABILITY TO ACCESS OR SEND COMMUNICATION OR DATA, PERSONAL INJURY OR DAMAGE, OR OTHER LOSS WHICH MAY ARISE FROM THE USE OF THIS PRODUCT. THE WARRANTY IS EXCLUSIVE AND ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE ARE EXPRESSLY DISCLAIMED.

FreeWave's Warranty does **not apply** in the following circumstances:

1. If Product repair, adjustments, or parts replacements are required due to accident, neglect, or undue physical, electrical, or electromagnetic stress.
2. If Product is used outside of FreeWave specifications as stated in the Product's data sheet.
3. If Product has been modified, repaired, or altered by Customer unless FreeWave specifically authorized such alterations in each instance in writing.

FreeWave Technologies, Inc.
5395 Pearl Parkway, Suite 100
Boulder, CO 80301
303-381-9200
Toll Free: 1-866-923-6168
Fax: 303-786-9948

Copyright © 2018 by FreeWave Technologies, Inc.
All rights reserved.

www.freewave.com

Table of Contents

Preface	5
1. Overview	7
1.1. Operation	8
1.1.1. Remote WC45i-GW-485s and Non-sleeping Radio Only Endpoints	8
1.1.2. Remote WC45i-GW-485 Endpoint Re-Scan	8
2. Equipment	9
2.1. Included Equipment	9
2.1.1. User-supplied Equipment	9
3. WC45i-GW-485 Connections	10
3.1. Connections	11
3.1.1. Connections - WC45i-BB	11
3.2. Power and Gateway Connections	13
4. WC Toolkit Installation	14
5. WC Toolkit Update	21
6. Configuration	24
7. Gateway Event Log	30
8. Firmware Updates	32
8.1. Gateway Firmware Update	33
8.2. Radio Firmware Update	35
8.3. Rescue Gateway (ARM) Bootload	37
9. Remote Endpoint Configuration	40
10. Remote Shutdown (RSD) and Local Digital Output Control	44
10.1. Example: WC45i-GW-485 Modbus Gateway Topology	45
10.2. Remote Shutdown Configuration	46
11. Slave Register Remapping	48
12. Modbus Gateway Register Map	51
12.1. Boolean Registers	52
12.2. Read / Write Registers	52
12.3. Read-only Registers	53
13. WC Toolkit Software Environment	56
13.1. Device Configuration window	57
13.1.1. Modbus Slaves Reporting table	62
13.2. Edit Configuration window	64
13.2.1. Edit Configuration window - General Sensor	65
13.3. Firmware Updates window	71
13.3.1. Update Gateway Firmware menu - Firmware Updates window	71
13.3.2. Update Radio Firmware menu - Firmware Updates window	72
13.4. Gateway Log window	73

13.4.1. Gateway Log tab	74
13.4.2. Log Statistics tab	76
13.5. (RegisterView) Slave 1 window	80
13.6. Remote Shutdown Settings window	84
13.6.1. Source Node (Endpoint) area	86
13.6.2. Relay Control Logic Section	88
Relay Details	88
13.6.3. Destination Counter / RSD Stick Section	90
13.7. Slave Register Remapping window	91
14. WAVECONTACT Network Frequencies	95
14.1. Radio Network Group Selection: 0, 1, 2, or 3	96
14.2. Radio Network Group Selection: 4, 5, 6, or 7	97
14.3. Radio Network Group Selection: 8, 9, 10, 11	98
14.4. Radio Network Group Selection: 12, 13, 14, 15	99
14.5. Radio Network Group Selection: 16, 17, 18, or 19	100
14.6. Radio Network Group Selection: 20, 21, 22, 23	101
14.7. Radio Network Group Selection: 24, 25, 26, 27	102
14.8. Radio Network Group Selection: 28 or 29	103
Appendix A: Technical Specifications	104
Appendix B: Connection Troubleshooting	106
Appendix C: LEDs	107
Appendix D: Available Accessories	108
Appendix E: FreeWave Legal Information	109

Preface

Contact FreeWave Technical Support

For up-to-date troubleshooting information, check the **Support** page at www.freewave.com.

FreeWave provides technical support Monday through Friday, 8:00 AM to 5:00 PM Mountain Time (GMT -7).

- Call toll-free at 1-866-923-6168.
- In Colorado, call 303-381-9200.
- Contact us through e-mail at moreinfo@freewave.com.

Other WAVECONTACT Information



Use the FreeWave <http://support.freewave.com> website to download the latest version of these documents.

Registration is required to use this website.

Document	Description	FreeWave Part Number
User Manual	The User Manual provides setup, configuration, and safety information for the WC45i-GW-485.	LUM0086AA
Quick Start Guide	The Quick Start Guide provides the out-of-the-box setup of the WC45i-GW-485.	QSG0035AA
Application Note	Remote Shutdown System	LAN5510AA

Document Styles

This document uses these styles:

- Parameter setting text appears as: **[Page=radioSettings]**
- File names appear as: **configuration.cfg**.
- File paths appear as: **C:\Program Files (x86)\FreeWave Technologies**.
- User-entered text appears as: **xxxxxxxxxx**.



Caution: Indicates a situation that **MAY** cause damage to personnel, the radio, data, or network.

Example: Provides example information of the related text.

FREEWAVE Recommends: Identifies FreeWave recommendation information.

Important!: Provides crucial information relevant to the text or procedure.

Note: Emphasis of specific information relevant to the text or procedure.



Tip Provides time saving or informative suggestions about using the product.



Warning! Indicates a situation that **WILL** cause damage to personnel, the radio, data, or network.

1. Overview

Thank you for purchasing the WC45i-GW-485 Modbus Gateway.

The WAVECONTACT WC45i-GW-485 has these features:

- AES 128-bit Encryption
- Class 1 Division 2 Area certification
- RS485 connection to a Modbus master device.
- Wide range DC power input: +6 to +36VDC.
- Collects and caches Modbus data from all WAVECONTACT remote devices.
- Provides configuration and status registers for remote configuration and status monitoring.
- Stores a maximum of 4700 register values from any combination of remote Endpoints.
- Supports transparent Modbus mode.
- Internal Remote Shut Down (RSD) logic control option.
- Slave register re-mapping.
- Remote configuration of WAVECONTACT devices through an Ethernet Gateway connection.
- Remote sensor configuration (PACTware™ and RadarMaster).
- Integrated 500mW FHSS 900MHz ISM band radio and high gain antenna.

Note: The terms node and Endpoint are used interchangeably in this document.

1.1. Operation

The WC45i-GW-485 supports all remote WAVECONTACT Endpoints. This allows all remote sensor data to be available in Modbus format.

- The register data from remote sensor Endpoints is available by requesting the remote Endpoint's Modbus Slave ID and register address from that Endpoint's register map.
- The WC45i-GW-485:
 - responds with the most recent copy of the data from the remote Endpoint.
 - automatically times out data from a remote Endpoint it stops receiving data for.

1.1.1. Remote WC45i-GW-485s and Non-sleeping Radio Only Endpoints

- Pre-configured remote Endpoints forward their set of registers to the Modbus Gateway on a pre-defined schedule (1 minute to 5 minutes is typical).
 - The register data is then buffered in the Gateway and can be read by the RTU at any time.
- If a Modbus request is received by the WC45i-GW-485 for a Modbus ID and address where buffered data does NOT exist but the Modbus ID is known, the Modbus request is forwarded to the remote Modbus Endpoint over the WAVECONTACT network.
 - The response is returned to the RTU.
- If a request for multiple registers is issued by the RTU **AND** if the WC45i-GW-485 does NOT have all registered data buffered, an exception is returned.
 - The system will NOT combine buffered and transparent data within a single Modbus response.

1.1.2. Remote WC45i-GW-485 Endpoint Re-Scan

It is possible to cause a remote WC45i-GW-485 to re-scan for attached Modbus devices by writing to one of the Gateway's configuration registers.

- This is useful to discover a Modbus device that is added to an existing Modbus Endpoint.
- The scan may be initiated by one of these methods:
 - If the radio address of the Gateway is known, writing this address to Gateway register 3000 will result in a scan.
 - If the Modbus ID of one of the already registered devices attached to a WC45i-GW-485 is known, a scan is started by writing the ID to Gateway register 3002.

2. Equipment

2.1. Included Equipment

The WC45i-GW-485 package contains these items:

Included Equipment - WC45i-GW-485	
Qty	Description
1	WC45i-GW - Gateway with Modbus Interface and 25ft cable
1	WC45i-BB - Smart Breakout Board
1	WC45i-GW-485 Quick Start Guide

2.1.1. User-supplied Equipment

- Small, flathead screwdriver
- Mounting equipment for the WC45i-GW-485.
- USB to Serial DB9 programming cable (FreeWave Part #: WC-USB-DB9)
- DC Adapter Power Supply (+6 to +36VDC)
- Barrel connector with Ground and Power flying leads
- Computer for WAVECONTACT device configuration.

Note: See [Available Accessories \(on page 108\)](#) for additional equipment.

3. WC45i-GW-485 Connections

- [Connections \(on page 11\)](#)
- [Power and Gateway Connections \(on page 13\)](#)

3.1. Connections

Important! The WC45i-GW-485 Modbus Gateway is configured using the **WC Toolkit**. Download the **WC Toolkit** software from <http://support.freewave.com/>. Registration is required to use this website.

Note: The **RS232 Config / Debug** connector on the WC45i-GW **MUST** be used for WC Toolkit access. The Config / Debug port is accessed by a direct connection to the WC45i-GW-485 **RS232 Config / Debug** connector port.

The WC45i-GW-485 uses a 6-conductor cable and the WC45i-BB Smart Breakout Board for power and serial communications.

3.1.1. Connections - WC45i-BB

The WC45i-BB Smart Breakout Board (FreeWave Part #: WC45i-BB, [Figure 1](#)), is used to:

- Connect to the RS232 lines (#2)
- Configure the WC45i-GW-485 system (#4).
- Power the WC45i-GW-485 (#5).

Important! The Signal Strength LEDs (#3) do NOT light at the Gateway as multiple Endpoints with varying signal strength may be connected at one time.




Figure 1: WC45i-BB Smart Breakout Board used with the WC45i-GW-485

WC45i-BB Smart Breakout Board Connections		
Location #	Title	Description
1	RS485 Modbus Block	Connect the Modbus master to the RS485 Modbus Block.
2	RS232 RS232 Config / Debug connector	The RS232 Config / Debug connector is for the USB to Serial DB9 programming cable (FreeWave Part # WC-USB-DB9).
3	Signal Strength LEDs	See LEDs (on page 107) for detailed information.
4	<ul style="list-style-type: none"> • BRN-B • GRN-A • YEL-RX • ORG-TX • BLK-GND • RED-PWR 	<ul style="list-style-type: none"> • RS485 B - 9600 Baud • RS485 A - 9600 Baud • RS232 Config / Debug connector RX - 9600 Baud • RS232 Config / Debug connector TX - 9600 Baud • Ground • Positive Power (+6 to +36VDC)
5	PWR GND	Power Source from an external power supply of +6 to +36VDC. External power ground.

3.2. Power and Gateway Connections

Important! Verify the items listed in [Equipment \(on page 9\)](#) are available before starting this procedure.

It is assumed that the reader and installer have completed the FreeWave WC45i-GW-485 installation and setup training to follow the procedures in this document.

1. All wiring should be neat and orderly.
2. On the WC45i-BB Smart Breakout Board:
 - a. Connect the configuration wires of the Gateway to their respective color-designated screw terminal connections.
 - b. Connect the Serial end of the WC-USB-DB9 cable to the **RS232 Config / Debug** connector port and the USB connection to the computer.
 - c. Use the PWR screw terminal connection to connect the Power Source from an external power supply of +6 to +36VDC.
 - d. Use the GND screw terminal connection to connect the External power ground.
 - e. Connect the Modbus master to the RS485 Modbus Block.

The WC45i-BB connections are similar to [Figure 2](#):



Figure 2: WC45i-BB Connections

3. If this is the first time the WC45i-GW-485 is installed, wait for the drivers to install.

Important! Depending on the computer and connection, the driver installation can take 3-6 minutes.

4. Continue with:
 - [WC Toolkit Installation \(on page 14\)](#)
 - [Configuration \(on page 24\)](#)

4. WC Toolkit Installation

Note: The images in this procedure are for Windows® 7 and/or Firefox®. The dialog boxes and windows may appear differently on each computer.

1. Click <http://support.freewave.com/>. The **FreeWave Support** site opens.

Important!: Registration is required to use this website.





Figure 3: FreeWave Login window

2. Enter the **User Name** and **Password**.

4. WC Toolkit Installation

3. Click .
A successful Login message briefly appears.
The **Help Topics** window opens.
4. Click the **Software** link.




Figure 4: Help Topics window

The **Software** window opens.

5. Click the **WAVECONTACT Toolkit** link.




Figure 5: Software window

The available software appears in the window.

6. Select and click the attachment.




Figure 6: WAVECONTACT Toolkit window

The **Opening** dialog box opens.




Figure 7: WC Toolkit Opening dialog box

Note: This procedure shows Firefox® dialog boxes. Other browsers will have different dialog boxes and procedures.

7. Click **OK**.
The **Enter name of file to save to** dialog box opens.

4. WC Toolkit Installation




Figure 8: Enter name of file to save to dialog box

8. Search for and select a location to save the **.zip** file to and click **Save**. The **Enter name of file to save to** dialog box closes.
9. Open a Windows® Explorer window and find the location where the **.zip** file was saved.
10. Double-click the **.zip** file.
11. Extract the **.exe** file from the **.zip** file into a parent location.
12. Double-click the **.exe** file to run the WC Toolkit installer. The **Open File - Security Warning** dialog box opens.




Figure 9: Open File - Security Warning dialog box

13. Click **Run**. The **User Account Control** dialog box opens.




Figure 10: User Account Control dialog box

14. Click **Yes**.
The **WC Toolkit Setup Wizard** starts.




Figure 11: WC Toolkit Setup Wizard - Select Destination Location window

15. Click **Next** to continue.
The **Ready to Install** window opens.

4. WC Toolkit Installation




Figure 12: WC Toolkit Setup Wizard - Ready to Install window

16. Click **Install**.
The install process is very quick.
The **Installation Complete** window opens.




Figure 13: WC Toolkit Setup Wizard - Installation Complete window

17. Click **Finish** to open WC Toolkit.
An **Update** message appears in the WC Toolkit window if an update is available.




Figure 14: WC Toolkit - Update Available message

18. Continue with the [WC Toolkit Update \(on page 21\)](#) procedure.

5. WC Toolkit Update

If the WAVECONTACT device is connected to the internet, WC Toolkit automatically searches for an update for either the WC Toolkit itself or the connected device's firmware.

An **Update Available** message appears if an update is available.

Note: An **Update Available** message also appears in the [Device Configuration window \(on page 57\)](#) for any connected WAVECONTACT device when an update is available for that device. The update procedure is the same for the device and WC Toolkit.

1. Open the **WC Toolkit** software.
The **Update Available** message appears in the window. ([Figure 15](#))




Figure 15: WC Toolkit - Update Available message

5. WC Toolkit Update

2. Click the **Update Available** message link.



Figure 16: Click the Update Available message link

The **Open File - Security Warning** dialog box opens.




Figure 17: Open File - Security Warning dialog box

3. Click **Run**.
The **User Account Control** dialog box opens.




Figure 18: User Account Control dialog box

4. Click **Yes**.

The WC Toolkit update process is very quick.

When the update is completed, WC Toolkit re-opens the **Select Device** window showing the updated software version in the WC Toolkit window. (Figure 19)




Figure 19: Select Device window

5. Continue with Configuration of the WC45i-GW-485.

6. Configuration

Note: The terms node and Endpoint are used interchangeably in this document.

FREEWAVE Recommends: Install and configure the **WC45i** Gateway before any Endpoints to ensure the Endpoints have connectivity after installation.

Important! The WC45i-GW-485 Modbus Gateway is configured using the **WC Toolkit**. Download the **WC Toolkit** software from <http://support.freewave.com/>. Registration is required to use this website.

Important! The **RS232 Config / Debug** connector on the WC45i-GW **MUST** be used for WC Toolkit access. The Config / Debug port is accessed by a direct connection to the WC45i-GW-485 **RS232 Config / Debug** connector port.

Procedure

Note: The screenshots are examples only.
The dialog boxes and windows appear differently on each computer.

1. Verify the WC Toolkit software is installed on the computer connected to the WC45i-GW-485.

Note: See [WC Toolkit Installation \(on page 14\)](#) and [WC Toolkit Update \(on page 21\)](#).

2. Open the **WC Toolkit** software.
The **Select Device** window opens. ([Figure 20](#))




Figure 20: Select Device window

3. Click the **Refresh** button to have WC Toolkit search for and list the available COM ports reported by Windows and connected devices in the **COM Port** list box.
4. Click the **COM Port** list box arrow and select the COM port on the computer associated with the connected WC45i-GW-485.
5. Click the **Auto-Detect Device on COM Port** button to have WC Toolkit connect the device to the COM Port selected in the **COM Port** list box.

Note: Optional: Click the **Select Device** list box arrow and select the connected WC45i-Gateway device.
Click the **Open Device Window** button to open the [Device Configuration window \(on page 57\)](#).




Figure 21: Select Device list box

The **Device Configuration** window opens for the selected device.

Note: See [Device Configuration window \(on page 57\)](#) for detailed information.

6. Configuration




Figure 22: Device Configuration window: WC45i-Gateway

6. In the **Settings** area (#5), change these settings:

Note: The **Network** settings are used to create separate networks using multiple Gateways (that are in close proximity to one another).

Important! The **Radio Network** and **Radio Network Group** settings are selected by the user but **MUST MATCH** the existing Gateway network for successful communication between the Gateway and Endpoint.
See [WAVECONTACT Network Frequencies \(on page 95\)](#) for additional information.

- Click the **Radio Network** list box arrow and select 0 (zero) to 7 for the assigned number.
 - Click the **Radio Network Group** list box arrow and select 0 (zero) to 29 for the network group assigned number.
 - Click the **Set** button to save the information.
7. In the **Set Encryption Key** area (#6), change these settings:
- In the **Key** text box, enter the encryption key for the device using 6 to 16 characters.
 - Click the **Set** button to save the information.

Important! A Key **CANNOT** contain spaces or angle brackets.
The Gateway and Endpoints only communicate if they are configured with the same **Key**.
When setting up a new network, use this same encryption Key on all the devices.

Note: When the WC45i-GW-485 drops its network, it attempts to join networks using the same encryption **Key**.

Caution: It is possible to hide the encryption **Key** so it cannot be read. This is the most secure option, but if the **Key** is forgotten, there is **no way to recover it**. The **Key** must be reset on every device on the network.

- Optional: Click the **Settings** menu and select **Set Encryption Key Unrecoverable** to permanently hide the key.




Figure 23: Settings menu > Set Encryption Key Unrecoverable

- Click **Refresh List** button to update the **Modbus Slaves Reporting** table with all connected remote Endpoints.




Slave ID	Node Type	Node Name	RSSI (dBm)	Register Quantity	Checkin Interval	TTL (min): Current/Max	Mainboard Firmware	Radio Firmware	Configure
1	WC20i-HART		-46	18	1 min	5/7	0.56	2.50 (sleeping)	<input type="checkbox"/>
5	WC30i-Pressur	Pressure1	-33	20	5 sec	1/2	0.74	2.50 (sleeping)	<input type="checkbox"/>

Figure 24: Modbus Slaves Reporting table

- Configure the Endpoints attached to the WC45i-GW-485.

Note: Use the Configuration procedure in the User Manual for these WAVECONTACT Endpoints:
 WC15i Multi-Input C1D1 Endpoint, WC20i Endpoint,
 WC30i Wireless Pressure Sensor, WC40i Modbus Endpoint,
 WC40i-COUNT Counter Endpoint, or WC40i-MB-RSD Modbus Endpoint.

- Optional: On the WC20i or WC45i-GW-485 Endpoint, press the **Check-in** button to apply power to the configured sensor, read the sensor values, and send the collected sensor data to the Gateway.
- Verify the Gateway is communicating with the Endpoints.

Note: A successful connection on the WAVECONTACT Endpoint is indicated with Green blinking  TX and ACT lights and a Red blinking  light for RX.
If the connection is NOT successful, a Green blinking  TX light appears for 10 seconds.

13. If applicable, continue with these other **WC45i** configuration procedures:
 - [Remote Endpoint Configuration \(on page 40\)](#)
 - [Remote Shutdown \(RSD\) and Local Digital Output Control \(on page 44\)](#)
 - [Slave Register Remapping \(on page 48\)](#)
14. Close the WC Toolkit software.
15. Remove the WC-USB-DB9 USB to Serial DB9 programming cable from the computer and the WC45i-BB.
16. As applicable, replace the Endpoint cover.
17. Mount the Gateway device.

7. Gateway Event Log

The Gateway keeps an internal log of events that are viewed in the [Gateway Log window \(on page 73\)](#) of WC Toolkit.

The **Gateway Log** window is used to log events such as reboots, remote Endpoints joining and/or timing out, local RSD control events, remote configuration sessions, firmware updates, etc.

Procedure

Note: The terms node and Endpoint are used interchangeably in this document.

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Tools** menu, click **View Gateway Log**.




Figure 25: Tools menu > View Gateway Log

The **Gateway Log** window opens.

The **Gateway Log** tab is active.

7. Gateway Event Log

Timestamp	Sequence	Event Type	Message
3/22/2017 4:31:40 PM	186	REMOTECONFIG	Session ended with Slave 1, Radio Address 27013
3/22/2017 4:18:35 PM	185	REMOTECONFIG	Session started with Slave 1, Radio Address 27013
3/22/2017 4:17:31 PM	184	REMOTECONFIG	Session ended with Slave 1, Radio Address 27013
3/22/2017 4:07:10 PM	183	REMOTECONFIG	Session started with Slave 1, Radio Address 27013
3/22/2017 3:54:25 PM	182	REMOTECONFIG	Session ended with Slave 1, Radio Address 27013
3/22/2017 3:41:25 PM	181	REMOTECONFIG	Session started with Slave 1, Radio Address 27013
3/22/2017 2:27:33 PM	180	NODEINFO	Slave 1 Added, Radio Address 27013, WC20-HART, Checkin Interval=1 min, RSSI=-34, BattV=3675
3/22/2017 2:18:39 PM	179	BOOTUP	Gateway Software Reboot, SupplyVoltage=8959mV
3/22/2017 2:18:39 PM	178	REBOOT	Reboot Reason: no modbus slaves
3/22/2017 2:16:39 PM	177	NODEINFO	Slave 1 Timed Out, Radio Address 27014, Sent Float, Checkin Interval=1 min, RSSI=-29, BattV=3398
3/22/2017 2:16:01 PM	176	REMOTECONFIG	Session started with Slave 1, Radio Address 27014
3/22/2017 2:09:46 PM	175	NODEINFO	Slave 1 Added, Radio Address 27014, Sent Float, Checkin Interval=1 min, RSSI=-39, BattV=3398
3/22/2017 2:08:15 PM	174	FIRMWARE	Radio Firmware Update: spiNode_300mv_v2.50.fw
3/22/2017 2:05:23 PM	173	FIRMWARE	Radio Firmware Update: spiNode_300mv_v2.50.fw
3/22/2017 2:03:39 PM	172	NODEINFO	Slave 1 Timed Out, Radio Address 27014, Sent Float, Checkin Interval=1 min, RSSI=-39, BattV=3626
3/22/2017 1:28:15 PM	171	NODEINFO	Slave 1 Added, Radio Address 27014, Sent TC, Checkin Interval=1 min, RSSI=-45, BattV=3613
3/22/2017 1:19:39 PM	170	BOOTUP	Gateway Software Reboot, SupplyVoltage=8841mV
3/22/2017 1:19:39 PM	169	REBOOT	Reboot Reason: no modbus slaves

Figure 26: Gateway Log window - Gateway Log tab

- Complete any of these options:
 - Click the **Refresh** or **Refresh List** button to update the information in the table.
 - Click the **Log Entries** list box arrow and select how many log entries to view on the **Gateway Log** tab.
 - Click the **Load Log from File** button to open the Microsoft® **Open** dialog box with the default location where the **.csv** file of the log information is saved.
 - Click the **Save Log to File** button to open the Microsoft® **Save As** dialog box with the default location to save the **.csv** file of the log information in.
- Optional: Click the **Log Statistics** tab to view statistics about the log events.

Slave ID	Node Type	Time Joined	Number of Timeouts	Last Time Out	RSSI (dBm)	Remote Configurations	Supply Voltage (mV)
1	Sent Float	3/22/2017 1:28:11 PM	1	3/22/2017 2:03:35 PM	-29	0	3398

Figure 27: Gateway Log window - Log Statistics tab

- Optional: Click the **Refresh** or **Refresh List** button to update the information in the table.
- Optional: Click the **Save Report to File** button to open the Microsoft® **Save As** dialog box with the default location to save the CSV version of the log file in.
- Close the **Gateway Log** window.

8. Firmware Updates

Firmware updates for both the Gateway and the built-in radio are completed over:

- the RS232 Config / Debug connector port using WC Toolkit.
- a remote TCP connection if a WC45i-GW-P Ethernet Gateway is used.

Note: These procedures are for both the WC45i-GW-485 and WC45i-GW-DIN devices.

- [Gateway Firmware Update \(on page 33\)](#)
- [Radio Firmware Update \(on page 35\)](#)
- [Rescue Gateway \(ARM\) Bootload \(on page 37\)](#)

8.1. Gateway Firmware Update

1. Verify the WC Toolkit software is installed on the computer connected to the WC45i-GW-485.

Note: See [WC Toolkit Installation \(on page 14\)](#) and [WC Toolkit Update \(on page 21\)](#).

2. Open the **WC Toolkit** software.
The **Select Device** window opens. (Figure 28)




Figure 28: Select Device window

3. Click the **Refresh** button to have WC Toolkit search for and list the available COM ports reported by Windows and connected devices in the **COM Port** list box.
4. Click the **COM Port** list box arrow and select the COM port on the computer associated with the connected WC45i-GW-485.
5. Click the **Auto-Detect Device on COM Port** button to have WC Toolkit connect the device to the COM Port selected in the **COM Port** list box.
The **Device Configuration** window opens for the selected device.
6. On the **Update** menu, click **Update Gateway Firmware**.




Figure 29: Updates menu > Update Gateway Firmware

The **Firmware Updates** window opens.

Note: See [Firmware Updates window \(on page 71\)](#) for detailed information.




Figure 30: Firmware Updates window

Note: By default, the latest firmware file is selected from the update server. When the **Update Gateway Firmware** menu is selected, the WC45i-Gateway searches for the most recent **modbusGW** file to update.

7. Click the **Start Transfer** button to load the file to the device.
8. Wait while the **Firmware Updates** window progress bar shows the file transfer.




Figure 31: Progress bar of firmware update

A message appears when the firmware update is successful.




Figure 32: Successful firmware update message

9. Click **OK** to close the message.

8.2. Radio Firmware Update

1. Verify the WC Toolkit software is installed on the computer connected to the WC45i-GW-485.

Note: See [WC Toolkit Installation \(on page 14\)](#) and [WC Toolkit Update \(on page 21\)](#).

2. Open the **WC Toolkit** software.
The **Select Device** window opens. (Figure 28)




Figure 33: Select Device window

3. Click the **Refresh** button to have WC Toolkit search for and list the available COM ports reported by Windows and connected devices in the **COM Port** list box.
4. Click the **COM Port** list box arrow and select the COM port on the computer associated with the connected WC45i-GW-485.
5. Click the **Auto-Detect Device on COM Port** button to have WC Toolkit connect the device to the COM Port selected in the **COM Port** list box.
The **Device Configuration** window opens for the selected device.
6. On the **Update** menu, click **Update Gateway Firmware**.




Figure 34: Updates menu > Update Radio Firmware

The **Firmware Updates** window opens.

Note: See [Firmware Updates window \(on page 71\)](#) for detailed information.




Figure 35: Firmware Updates window

Note: By default, the latest firmware file is selected from the update server. When the **Update Radio Firmware** menu is selected, the WC45i-Gateway searches for the most recent **appNode** file to update.

7. Click the **Start Transfer** button to load the file to the device.
8. Wait while the **Firmware Updates** window progress bar shows the file transfer.




Figure 36: Progress bar of firmware update

A message appears when the firmware update is successful.




Figure 37: Successful firmware update message

9. Click **OK** to close the message.

8.3. Rescue Gateway (ARM) Bootload

Possible causes to run a **Rescue Bootload**:

- Power failure.
- Communications failure during firmware update process.
- The base LED is solid on and/or the WC Toolkit is unable to communicate with the Gateway.

Procedure

1. Remove the DC power from the Gateway.
2. Verify the WC Toolkit software is installed on the computer connected to the WC45i-GW-485.

Note: Download the **WC Toolkit** software from <http://support.freewave.com/>.

3. Open the **WC Toolkit** software.
The **Select Device** window opens. (Figure 28)




Figure 38: Select Device window

4. Click the **Refresh** button to have WC Toolkit search for and list the available COM ports reported by Windows and connected devices in the **COM Port** list box.
5. Click the **COM Port** list box arrow and select the COM port on the computer associated with the connected WC45i-GW-485.
6. Click the **Auto-Detect Device on COM Port** button to have WC Toolkit connect the device to the COM Port selected in the **COM Port** list box.
The **Device Configuration** window opens for the selected device.
7. On the **Update** menu, click **Update Gateway Firmware**.




Figure 39: Updates menu > Update Gateway Firmware

The **Firmware Updates** window opens.

Note: See [Firmware Updates window \(on page 71\)](#) for detailed information.




Figure 40: Firmware Updates window

Note: By default, the latest firmware file is selected from the update server. When the **Update Gateway Firmware** menu is selected, the WC45i-Gateway searches for the most recent **modbusGW** file to update.

8. Click the **Start Transfer** button to load the file to the device.

Wait while the **Firmware Updates** window progress bar shows the file transfer.




Figure 41: Progress bar of firmware update

A message appears when the firmware update is successful.




Figure 42: Successful firmware update message

9. Re-connect the DC power to the Gateway.
The firmware update process starts.

Note: If the firmware update does NOT start, remove power for at least 10 seconds and re-try.

9. Remote Endpoint Configuration

The WC45i-GW-485 Modbus Gateway allows configuration changes to be made to any of the connected WAVECONTACT remote Endpoints wirelessly.

- The WC45i-GW-485 requires an initial configuration using the Config / Debug connector.
- The Config / Debug port is accessed by a direct connection to the WC45i-GW-485 **RS232 Config / Debug** connector port.

Note: This procedure assumes WC Toolkit has been installed.
Download the **WC Toolkit** software from <http://support.freewave.com/>.
Registration is required to use this website.

Procedure

Note: The terms node and Endpoint are used interchangeably in this document.

1. Open the [Device Configuration window \(on page 57\)](#).
2. In the **Configure** column, select the check-box next to the Endpoint to configure.

9. Remote Endpoint Configuration




Figure 43: Detail of Endpoint in Modbus Slaves Reporting Table

3. Click the **Start Configuration** button to activate a **Remote Configuration** session.
 - If the Endpoint has a **Non-Sleeping** radio, the **Remote Configuration** session is ready immediately.
 - If it is a **Sleeping** device, wait for the Endpoint to either check-in or send a beacon so it can be commanded into **Configuration** mode.
 - A WC20i Endpoint sends a beacon every 2½ minutes.
 - All other **Sleeping** Endpoints send a beacon every 5½ minutes.
 - When the device has entered a **Remote Configuration** session, a message indicating the **Slave is Ready** appears.




Figure 44: Remote Configuration area - Slave is Ready

4. Click the **Configure** button to open the [Edit Configuration window \(on page 64\)](#).

Important! The **Remote Configuration** session automatically times out after 10 minutes of inactivity and the Endpoint will resume normal operation.

Note: The **Edit Configuration** window is unique for the selected Endpoint device. [Figure 45](#) shows the **Edit Configuration** window for a WC20i-HART Endpoint.

9. Remote Endpoint Configuration







Figure 45: Edit Configuration window - WC20i-HART

5. Make any necessary changes in the active areas of the window and click the corresponding **Set** button to save the changes.
6. When finished changing the configuration, close the **Edit Configuration** window and return to the **Device Configuration** window.
7. Click the **End** button to stop the **Remote Configuration** session.

Note: The Remote Configuration session automatically times-out after 10 minutes of inactivity.

8. Optional: On the WC20i or WC45i-GW-485 Endpoint, press the **Check-in** button to apply power to the configured sensor, read the sensor values, and send the collected sensor data to the Gateway.
9. Verify the Gateway is communicating with the Endpoints.

Note: A successful connection on the WAVECONTACT Endpoint is indicated with Green blinking  TX and ACT lights and a Red blinking  light for RX.
If the connection is NOT successful, a Green blinking  TX light appears for 10 seconds.

10. Close the WC Toolkit software.
11. Remove the WC-USB-DB9 USB to Serial DB9 programming cable from the computer and the WC45i-BB.
12. As applicable, replace the Endpoint cover.
13. Mount the Gateway device.

10. Remote Shutdown (RSD) and Local Digital Output Control

The WC45i-GW-485 Modbus Gateway supports Internal Logic Control capability which enables the Gateway to control output relays on the WC40i-MB-RSD Modbus Endpoint or WC40i-COUNT.

Note: The WC40i-MB-RSD Modbus Endpoint bundle includes the WC40i-MB and the WC40i-RSD products.

- The WC45i-GW-485 receives data from multiple remote Endpoints.
- The data is used from those remote Endpoints to set the relay output on one or more remote WC40i-MB-RSD or WC40i-COUNT.
 - An example of the topology is shown in [Figure 46](#).

Note: See [Connections \(on page 11\)](#) for port locations.

Use the [Remote Shutdown Configuration \(on page 46\)](#) procedure to control the output relays.

10.1. Example: WC45i-GW-485 Modbus Gateway Topology




Figure 46: Example: WC45i-GW-485 Modbus Gateway Topology

10.2. Remote Shutdown Configuration

Note: The terms node and Endpoint are used interchangeably in this document.

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Settings** menu, click **Remote Shutdown Settings**.




Figure 47: Settings menu > Remote Shutdown Settings

The [Remote Shutdown Settings window \(on page 84\)](#) opens.




Figure 48: Remote Shutdown Settings window

3. As appropriate, complete these sections of the window:
 - a. [Source Node \(Endpoint\) area \(on page 86\)](#).
 - b. [Relay Control Logic Section \(on page 88\)](#).
 - c. [Destination Counter / RSD Stick Section \(on page 90\)](#).
4. Click the **Write Remote Shutdown Settings to Gateway** button to store the settings in the WC45i-Gateway.
5. Optional: Click the **Failsafe Enabled** check box to require ALL rules to have valid data for the relay to be energized.

10. Remote Shutdown (RSD) and Local Digital Output Control

Important! If one or more of the Endpoints time-out or does not exist, the relay is de-energized.
If this option is NOT selected, then an Endpoint that is not installed or fails to check in is ignored and the relay is energized using logic only from the units that are active.

6. Optional: Click the **Latch De-Energized** check box so the rules may only de-energize the relay.

Note: For the relay to be energized again, a Modbus write from a PLC to the Gateway for the destination WC40i-MB-RSD or WC40i-COUNT relay must occur.
This is useful if manual intervention is required before the relay is energized after an event.
In [10](#), a Modbus coil write to Slave ID 5 relay channel 1 (which is register 1) is required to energize the relay.

11. Slave Register Remapping

The Gateway allows any of the remote register data to be remapped to a single block of registers available at the Gateway's Slave ID.

Note: The default is 247.

- This is useful for collecting a subset of register data from multiple Endpoints and making it readable in a single block of registers.
- A maximum of 750 registers can be remapped to the Gateway's Slave ID starting at register 5000.

Procedure

Note: The terms node and Endpoint are used interchangeably in this document.

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Settings** menu, click **Slave Register Remapping**.




Figure 49: Settings menu > Slave Register Remapping

11. Slave Register Remapping

The [Slave Register Remapping window](#) (on page 91) opens.




Figure 50: Slave Register Remapping window

- In the **Slave ID** column / text box, enter the remote source Endpoint Modbus Slave ID.

Important! Verify there are no duplicate Slave IDs in a given network. The Gateway only caches one set of data for each Slave ID. A duplicate is overwritten.

- In the **Register Address** column text box, enter the register address to map to each Gateway register.

Note: The **Node Name**, **Data Type**, **Register Value**, and **Description** columns are automatically filled in by the Gateway once the mapping is written to the Gateway.

- Click the **Write Mapping to Gateway** button to remap the registers.

[Figure 51](#) shows an example of a the **Slave Register Remapping** window.

- Slave ID 1** is a **WC20i-AN Analog Endpoint** mapped to have sensor current, RSSI and battery voltage available at Gateway registers 5000 through 5002.
- Slave ID 5** is NOT reporting data to the Gateway so its registers are failing high.

	Remapped Address	Slave ID	Register Address	Node Name	Data Type	Register Value	Description
▶	5000	1	3001	Analog4-20	16bit UINT	14479	Sensor A Current (uA)
	5001	1	65531	Analog4-20	16bit INT	-47	RSSI (dB)
	5002	1	65532	Analog4-20	16bit UINT	3195	Battery Voltage (mV)
	5006	5	65532	Digital	16bit UINT	3236	Battery Voltage (mV)
	5007	5	3001		16bit UINT	65535	
	5008	5	65531		16bit INT	-1	RSSI (dB)
	5009	5	65532		16bit UINT	65535	Battery Voltage (mV)

Figure 51: Example of the Slave Register Remapping window

Important! If the Gateway does NOT have data for a remapped value, it will respond with 0xFFFF, or 0x0000 for the register request.
Use the Fail Mode settings to configure this globally.

Note: 0xFFFF = 65535, 0x0000 = 0.

12. Modbus Gateway Register Map

Important! By default, the WAVECONTACT Modbus Gateway is assigned Modbus **Slave ID** number 247.

- Only the Gateway status / configuration registers are read at this address.
- All remote Endpoint registers are read from the **Slave ID** and **Register Address** of the remote Endpoint, unless the [Slave Register Remapping \(on page 48\)](#) procedure is used.
- Registers include:
 - [Boolean Registers \(on page 52\)](#)
 - [Read / Write Registers \(on page 52\)](#)
 - [Read-only Registers \(on page 53\)](#)

12.1. Boolean Registers

- These are 1-bit coil registers.
- They can only be written to Modbus opcode 0x05 (Write Single Coil).
- Writing 0x0000 to a coil has **NO** effect.
- To perform these resets, write a 0xFF00 to the respective coil:

Boolean Registers		
Register Number	Register Address (Offset)	Description
00001	0000	Resets the Gateway and radio.
00002	0001	Resets the radio leaving the Gateway on.
00003	0002	Resets all counters to zero.

Note: See [Modbus Gateway Register Map \(on page 51\)](#) 2026-2031.

12.2. Read / Write Registers

- These are 16-bit read/write registers.
- They can be written to by Modbus opcode 0x06 or 0x10 (Write Single and Multiple Registers, respectively).
- They can be read with Modbus opcode 0x03 or 0x04 (Read Discrete Input and Holding Registers, respectively).
- The first three registers are identical to the previous three write coils and behave similarly.
- They will be read as 0x0000 and can be triggered by writing 0xFF00 to them.
- The remaining must be written with 16-bit values in the range specified in the [Read / Write Registers \(on page 52\)](#) table:

Read / Write Registers		
Register Number	Register Address (Offset)	Description
41001	1000	Resets the Gateway and radio
41002	1001	Resets the radio leaving the Gateway on
41003	1002	Resets all GW status counters to zero.

Note: See [Modbus Gateway Register Map \(on page 51\)](#) 2026-2031.

12.3. Read-only Registers

- These are 16-bit Read-only registers.
- They can be read with Modbus opcode 0x03 or 0x04 (Read Discrete Input and Holding Registers, respectively).

Note: If the Gateway has a large total number of registers approaching 4700, register 2008 should be monitored to ensure that free registers are available before adding a new Endpoint.

Read-only Registers		
Register Number	Register Address (Offset)	Description
42001	2000	Upper 16 bits of SFTS GW Endpoint address (the radio ID).
42002	2001	Lower 16 bits of SFTS GW Endpoint address (the radio ID).
42003	2002	Upper 16 bits of Radio Firmware version number.
42004	2003	Lower 16 bits of Radio Firmware version number.
42005	2004	Upper 16 bits of Gateway firmware version number.
42006	2005	Lower 16 bits of Gateway firmware version number.
42007	2006	Number of slave Endpoints that data is cached for this Gateway.
42008	2007	Total number of registers allocated to slave devices.
42009	2008	Total number of free registers available for slave devices.
42010	2009	Bitmask for active slave IDs 15-0 (LSB is 0).
42011	2010	Bitmask for active slave IDs 31-16 (LSB is 16).
42012	2011	Bitmask for active slave IDs 47-32 (LSB is 32).
42013	2012	Bitmask for active slave IDs 63-48 (LSB is 48).
42014	2013	Bitmask for active slave IDs 79-64 (LSB is 64).
42015	2014	Bitmask for active slave IDs 95-80 (LSB is 80).
42016	2015	Bitmask for active slave IDs 111-96 (LSB is 96).
42017	2016	Bitmask for active slave IDs 127-112 (LSB is 112).
42018	2017	Bitmask for active slave IDs 143-128 (LSB is 128).
42019	2018	Bitmask for active slave IDs 159-144 (LSB is 144).
42020	2019	Bitmask for active slave IDs 175-160 (LSB is 160).
42021	2020	Bitmask for active slave IDs 191-176 (LSB is 176).
42022	2021	Bitmask for active slave IDs 207-192 (LSB is 192).
42023	2022	Bitmask for active slave IDs 223-208 (LSB is 208).

12. Modbus Gateway Register Map

Read-only Registers		
Register Number	Register Address (Offset)	Description
42024	2023	Bitmask for active slave IDs 239-224 (LSB is 224).
42025	2024	Bitmask for active slave IDs 255-240 (LSB is 240).
42026	2025	Gateway power supply voltage in mV.
42027	2026	Radio packets received count.
42028	2027	Radio packets sent count.
42029	2028	RS-485 messages received count.
42030	2029	RS-485 messages sent count .
42031	2030	Total Modbus errors from master and slaves.
42032	2031	Modbus exceptions from slave Endpoints.
42033	2032	Radio packets received / transmitted per minute. FREEWAVE Recommends: Less than 60
42034	2033	Radio packets per minute alert. <ul style="list-style-type: none"> • 0 (zero) if packets/min <= 60. • 1 if packets/min > 60.
42101	2100	Address test register. Note: This register always returns 2100.
42102	2101	Address test register. Note: This register always returns 2101.
42103	2102	Address test register. Note: This register always returns 2102.
43001	3000	Writes the radio address of an Endpoint to this register to cause that WC45i-GW-485 to perform a scan for attached Modbus sensors.
43004	3003	Writes Modbus ID for a Modbus Client Endpoint to this register to cause that remote Endpoint to perform a scan for attached Modbus sensors.
44002	4001	Status of Slave ID 1. Note: This register returns 1 if Slave is present and 0 (zero) if Slave is not present.

Read-only Registers		
Register Number	Register Address (Offset)	Description
44003	4002	Status of Slave ID 2. Note: This register returns 1 if Slave is present and 0 (zero) if Slave is not present.
44241	4240	Status of Slave ID 240. Note: This register returns 1 if Slave is present and 0 (zero) if Slave is not present.

13. WC Toolkit Software Environment

The WC Toolkit software environment uses these windows to configure all WAVECONTACT devices:

- [Device Configuration window \(on page 57\)](#)
- [Edit Configuration window \(on page 64\)](#)
- [Firmware Updates window \(on page 71\)](#)
- [Gateway Log window \(on page 73\)](#)
- [Remote Shutdown Settings window \(on page 84\)](#)
- [Slave Register Remapping window \(on page 91\)](#)

13.1. Device Configuration window

The **Device Configuration** window is used to configure the settings on the WC45i-GW-485 Modbus Gateway.

- If one or more remote Endpoints are configured with the correct network settings they send their data to the Gateway.
- The Gateway shows the Endpoint type, Endpoint name, RSSI signal strength, programmed Endpoint check-in interval, the Time To Live (TTL), and the Endpoints radio and main firmware versions.

Access and Window Description

1. Verify the WC Toolkit software is installed on the computer connected to the WC45i-GW-485.

Note: See [WC Toolkit Installation \(on page 14\)](#) and [WC Toolkit Update \(on page 21\)](#).

2. Open the **WC Toolkit** software.
The **Select Device** window opens. (Figure 52)




Figure 52: Select Device window

3. Click the **Refresh** button to have WC Toolkit search for and list the available COM ports reported by Windows and connected devices in the **COM Port** list box.
4. Click the **COM Port** list box arrow and select the COM port on the computer associated with the connected WC45i-GW-485.
5. Click the **Auto-Detect Device on COM Port** button to have WC Toolkit connect the device to the COM Port selected in the **COM Port** list box.

Note: Optional: Click the **Select Device** list box arrow and select the connected WC45i-Gateway device.

The **Device Configuration** window opens for the selected device.




Figure 53: Device Configuration window: WC45i-Gateway

Device Configuration window: WC45i-GW-485		
Control Area	Control Title	Control Description
	Set button	Click the Set button to save the information.
1 - Status of Last Operation text box		<p>The Status of Last Operation text box indicates whether the last command from the WC Toolkit to the connected device is Active or has Passed.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: A Firmware Update Available message appears in this text box when the WC Toolkit has detected that a newer version of firmware is available for download than what is installed on the device.</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: This information is read-only.</p> </div>
2 - Serial Port Settings area		The Serial Port Settings area shows the connected COM port and is used to re-connect to the COM port if the connection is lost.
2 - Serial Port Settings area	COM Port list box	Click the COM Port list box arrow and select the COM port on the computer associated with the connected WC45i-GW-485.

Device Configuration window: WC45i-GW-485		
Control Area	Control Title	Control Description
2 - Serial Port Settings area	Refresh button	Click the Refresh button to have WC Toolkit search for and list the available COM ports reported by Windows and connected devices in the COM Port list box.
2 - Serial Port Settings area	COM text box	The COM text box shows the COM port the WAVECONTACT device is connected to. Note: This information is read-only.
2 - Serial Port Settings area	Open button	Click the Open button to re-connect the WAVECONTACT device to the COM port.
2 - Serial Port Settings area	Close button	Click the Close button to disconnect the WAVECONTACT device from the COM port.
2 - Serial Port Settings area	Offline button	Click the Offline button to disconnect the WAVECONTACT device from the COM port but continue to configure the device offline.
2 - Serial Port Settings area	TCP Connection check box	Note: The TCP Connection check box is only available for the WC45i-GW-P Ethernet Gateway.
2 - Serial Port Settings area	Connect / Update button	Click the Connect / Update button to re-connect to the COM port of the WAVECONTACT device.
3 - Modbus Slaves Reporting table		The Modbus Slaves Reporting table shows all connected remote Endpoints. Note: This information is read-only. See the Modbus Slaves Reporting table (on page 62) for detailed information about the table.
4 - Information area		The Information area of the Device Configuration window shows connection information about the connected WAVECONTACT device. Note: This information is read-only.
5 - Settings area		The Settings area is used to define the radio mode and radio network.

Device Configuration window: WC45i-GW-485		
Control Area	Control Title	Control Description
5 - Settings area	Radio Network list box	<p>Click the Radio Network list box arrow and select 0 (zero) to 7 for the assigned number.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: The default value is 1.</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Important!: The Radio Network and Radio Network Group settings are selected by the user but MUST MATCH the existing Gateway network for successful communication between the Gateway and Endpoint. See WAVECONTACT Network Frequencies (on page 95) for additional information.</p> </div>
5 - Settings area	Radio Network Group list box	<p>Click the Radio Network Group list box arrow and select 0 (zero) to 29 for the network group assigned number.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: The default value is 10.</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Important!: The Radio Network and Radio Network Group settings are selected by the user but MUST MATCH the existing Gateway network for successful communication between the Gateway and Endpoint. See WAVECONTACT Network Frequencies (on page 95) for additional information.</p> </div>
6 - Set Encryption Key area		The Set Encryption Key area is used to activate and define the encryption key for the WAVECONTACT device.
6 - Set Encryption Key area	Help button	Click to open the Encryption Help message.
6 - Set Encryption Key area	Key text box	<p>In the Key text box, enter the encryption key for the device using 6 to 16 characters.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Important!: A Key CANNOT contain spaces or angle brackets. The Gateway and Endpoints only communicate if they are configured with the same Key.</p> </div>

Device Configuration window: WC45i-GW-485		
Control Area	Control Title	Control Description
7 - Gateway RS485 Settings area		<p>The Gateway RS485 Settings area is used to define the RS485 settings and communication timing.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: The Gateway has registers that are read for diagnostics. They are not often used except when remapping Modbus data. When remapping, read all data from this Slave ID.</p> </div>
7 - Gateway RS485 Settings area	Gateway Slave ID list box	Click the Gateway Slave ID list box arrow and select the Modbus Slave ID for the Gateway.
7 - Gateway RS485 Settings area	Baud Rate list box	Click the Baud Rate list box arrow and select the baud rate for the RS485 Modbus port.
7 - Gateway RS485 Settings area	UART Mode list box	Click the UART Mode list box arrow and select the number of data bits, parity, and stop bits used with the RS485 Modbus port.
8 - Gateway Slave ID Word / Byte Order area		The Gateway Slave ID Word / Byte Order area is used to set communication timing by selecting one of the byte order options for transmission of Modbus data.
8 - Gateway Slave ID Word / Byte Order area	High Word / High Byte (ABCD) option button	Select the High Word / High Byte (ABCD) option button to transmit the Modbus data in a High Word / High Byte order.
8 - Gateway Slave ID Word / Byte Order area	High Word / Low Byte (BACD) option button	Select the High Word / Low Byte (BACD) option button to transmit the Modbus data in a High Word / Low Byte order.
8 - Gateway Slave ID Word / Byte Order area	Low Word / High Byte (CDAB) option button	Select the Low Word / High Byte (CDAB) option button to transmit the Modbus data in a Low Word / High Byte order.
8 - Gateway Slave ID Word / Byte Order area	Low Word / Low Byte (DCBA) option button	Select the Low Word / Low Byte (DCBA) option button to transmit the Modbus data in a Low Word / Low Byte order.
9 - Remote Configuration area		The Remote Configuration area is used to start and end a Remote Configuration session.

Device Configuration window: WC45i-GW-485		
Control Area	Control Title	Control Description
9 - Remote Configuration area	Start Configuration button	<p>Click the Start Configuration button to activate a Remote Configuration session.</p> <ul style="list-style-type: none"> • If the Endpoint has a Non-Sleeping radio, the Remote Configuration session is ready immediately. • If it is a Sleeping device, wait for the Endpoint to either check-in or send a beacon so it can be commanded into Configuration mode. <ul style="list-style-type: none"> • A WC20i Endpoint sends a beacon every 2½ minutes. • All other Sleeping Endpoints send a beacon every 5½ minutes. • When the device has entered a Remote Configuration session, a message indicating the Slave is Ready appears.
9 - Remote Configuration area	Configure button	Click the Configure button to open the Edit Configuration window (on page 64) .
9 - Remote Configuration area	End button	<p>Click the End button to stop the Remote Configuration session.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: The Remote Configuration session automatically times-out after 10 minutes of inactivity.</p> </div>

13.1.1. Modbus Slaves Reporting table

Device Configuration window: Modbus Slaves Reporting table	
Control Title	Control Description
Auto Refresh check box	Select the Auto Refresh check box to automatically update the information in the table every 10 seconds.
Refresh List button	Click the Refresh or Refresh List button to update the information in the table.
Slave ID column	The Slave ID column / text box shows the remote source Endpoint Modbus Slave ID selected in the Settings area of the Device Configuration window.
Node Type column	The Node Type column shows the type of Endpoint attached to the WC45i-Gateway.
Node Name column	The Node Name column / text box shows the name assigned to the Endpoint in the Settings area of the Device Configuration window.

Device Configuration window: Modbus Slaves Reporting table	
Control Title	Control Description
RSSI (dbm) column	<p>The RSSI (dbm) column / text box shows the signal strength received from the Endpoint to its neighbor (e.g., a neighbor could be the Gateway if it is not hopping).</p> <p>Example: The RSSI is adjusted so if a 500mW device is communicating to a 40mW device the RSSI is shown as being equal in both directions at the lower signal strength.</p> <p>Notes</p> <ul style="list-style-type: none"> • All communications are bi-directional so messages are needed in both directions for communications. • The RSSI and TTL values are color coded (green, yellow, orange, red) to indicate the relative link quality of an Endpoint. Red=Bad link, Yellow=OK link, Green=Good link.
Register Quantity column	The Register Quantity column shows the number of Modbus register data points available the Endpoint has reported to the Gateway.
Checkin Interval column	The Checkin Interval column shows the check-in time selected in the Checkin Interval list box of the Settings area of the Device Configuration window.
TTL (min): Current / Max column	<p>The TTL Current is set to the TTL Max each time an update is received from that Endpoint.</p> <ul style="list-style-type: none"> • The TTL Current indicates the number of minutes remaining until the Endpoint is timed out of the Gateway if no updates are received. • The TTL Max indicates the maximum TTL for that Endpoint. <p>Note: The RSSI and TTL values are color coded (green, yellow, orange, red) to indicate the relative link quality of an Endpoint. Red=Bad link, Yellow=OK link, Green=Good link.</p>
Mainboard Firmware column	The Mainboard Firmware column shows the version of firmware currently installed on the mainboard of the Gateway.
Radio Firmware column	The Radio Firmware column shows the version of radio firmware currently installed on the Endpoint.
Configure column	In the Configure column, select the check-box next to the Endpoint to configure.

13.2. Edit Configuration window

The **Edit Configuration** window is used to configure individual Endpoints in the network.

Access and Window Description

1. Open the [Device Configuration window \(on page 57\)](#).
2. In the **Configure** column, select the check-box next to the Endpoint to configure.
3. Click the **Start Configuration** button to activate a **Remote Configuration** session.

When the device has entered a **Remote Configuration** session, a message indicating the **Slave is Ready** appears.




Figure 54: Remote Configuration area - Slave is Ready

4. Click the **Configure** button to open the **Edit Configuration** window.

The **Edit Configuration** window opens with device-specific control options depending on the connected sensor:

- [Edit Configuration window - General Sensor \(on page 65\)](#)

13.2.1. Edit Configuration window - General Sensor




Figure 55: Edit Configuration window


Edit Configuration window - General Sensor		
Control Area	Control Title	Control Description
	Set button	Click the Set button to save the information.
Status of Last Operation text box		<p>The Status of Last Operation text box indicates whether the last command from the WC Toolkit to the connected device is Active or has Passed.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: A Firmware Update Available message appears in this text box when the WC Toolkit has detected that a newer version of firmware is available for download than what is installed on the device.</p> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: This information is read-only.</p> </div>

Edit Configuration window - General Sensor		
Control Area	Control Title	Control Description
2 - General area	Checkin Interval list box	Click the Checkin Interval list box arrow and select how often the Endpoint wakes up, reads the , and transmits the data to the Gateway.
2 - General area	Slave ID text box	In the Slave ID column / text box, enter the remote source Endpoint Modbus Slave ID. Important! Verify there are no duplicate Slave IDs in a given network. The Gateway only caches one set of data for each Slave ID. A duplicate is overwritten.
2 - General area	Node Name text box	In the Node Name text box, enter a name for the Endpoint using a maximum of 10 characters.
2 - General area	Radio Mode list box	Click the Radio Mode list box arrow and select either Sleeping or Non-Sleeping .
3 - WC45i-GW-485 Information area		The Information area of the Device Configuration window shows connection information about the connected WAVECONTACT device. Note: This information is read-only.
3 - WC45i-GW-485 Information area	Force Device to Checkin to Gateway button	Click the Force Device to Checkin to Gateway button to force the Endpoint to send data to the WC45i-GW-485, WC45i-GW-AN, or WC45i-GW-DIN.
3 - WC45i-GW-485 Information area	Refresh button	Click the Refresh button to update the information in this area.
4 - Sensor Power area	Sensor A On Time (sec) text box	In the Sensor A On time (sec) text box, enter the number of seconds . FREEWAVE Recommends: Accept the default Sensor A On time (sec) value of 2 seconds for most devices. However, radar sensors often require a longer warm-up time.

Edit Configuration window - General Sensor		
Control Area	Control Title	Control Description
4 - Sensor Power area	Sensor Always On check box	Select the Sensor Always On check box to make the sensor always have power no matter what type of power source is connected to the device. Note: Having the Sensor Always On selected is useful for rapid data collection on a sensor that has a long warm-up time. However, it will shorten the battery life dramatically unless a Solar Powered WC20i is used.
4 - Sensor Power area	Sensor B On Time (sec) text box	In the Sensor B On Time (sec) text box, enter the number of seconds a second sensor powers on before its value is read.
4 - Sensor Power area	Sensor Power Mode list box	Click the Sensor Power Mode list box arrow and select either HIGH or LOW volts for the WC20i. Note: HIGH outputs 18.5 volts to the sensor and LOW outputs 12.5 volts. LOW results in longer battery life but some sensors require a higher voltage. In 4-20mA mode HIGH is automatically selected and is the only option. It will supply a minimum of 13.5V to the sensor at full load.
4 - Sensor Power area	Manual Loop Power Control button	Click the Manual Loop Power Control button to send power to the sensor so the sensor can be configured. Note: The loop times out after a short time if it is not shut off.
4 - Sensor Power area	Channel A option button	Select the Channel A option button to assign the changed settings to Channel A in a 2-channel device.
4 - Sensor Power area	Channel B option button	Select the Channel B option button to assign the changed settings to Channel B in a 2-channel device.
5 - Analog 4-20mA / 1-5V Scaling area	Scale A Type list box	Click the Scale A Type or Scaling B Type list box arrow and select either a 4-20mA or 1-5V sensor to scale to an engineering unit equivalent (e.g., 4-20mA = 0-1000 PSI). Note: If None is selected, there is no scaling of the analog readings to engineering units.

Edit Configuration window - General Sensor		
Control Area	Control Title	Control Description
5 - Analog 4-20mA / 1-5V Scaling area	Scaling A Low Value text box	<p>In the Scaling A or B Low Value text box, manually enter the sensor's lower range value.</p> <p>Note: By default, the Scaling A or B Low Value corresponds with the lowest reading from the sensor, either 4mA or 1V, depending on the selection in the Scale A Type list box or Scale B Type list box.</p>
5 - Analog 4-20mA / 1-5V Scaling area	Scaling A High Value text box	<p>In the Scaling A or B High Value text box, manually enter the sensor's upper range value.</p> <p>Note: By default, the Scaling A or B High Value corresponds with the highest reading from the sensor, either 20mA or 5V, depending on the selection in the Scale A Type list box or Scale B Type list box.</p>
5 - Analog 4-20mA / 1-5V Scaling area	Scaling B Type list box	<p>Click the Scale A Type or Scaling B Type list box arrow and select either a 4-20mA or 1-5V sensor to scale to an engineering unit equivalent (e.g., 4-20mA = 0-1000 PSI).</p> <p>Note: If None is selected, there is no scaling of the analog readings to engineering units.</p>
5 - Analog 4-20mA / 1-5V Scaling area	Scaling B Low Value text box	<p>In the Scaling A or B Low Value text box, manually enter the sensor's lower range value.</p> <p>Note: By default, the Scaling A or B Low Value corresponds with the lowest reading from the sensor, either 4mA or 1V, depending on the selection in the Scale A Type list box or Scale B Type list box.</p>
5 - Analog 4-20mA / 1-5V Scaling area	Scaling B High Value text box	<p>In the Scaling A or B High Value text box, manually enter the sensor's upper range value.</p> <p>Note: By default, the Scaling A or B High Value corresponds with the highest reading from the sensor, either 20mA or 5V, depending on the selection in the Scale A Type list box or Scale B Type list box.</p>
6 - Digital I/O area	State Change Checkin list box	<p>Click the State Change Checkin list box arrow and select Yes to check on a change of state at the input rather than waiting for the check in time to expire.</p>
6 - Digital I/O area	Channel 1 Mode list box	<p>Click the Channel 1 Mode list box arrow and select either INPUT (analog or digital) or OUTPUT (relay control) for Channel 1.</p>

Edit Configuration window - General Sensor		
Control Area	Control Title	Control Description
6 - Digital I/O area	Channel 2 Mode list box	Click the Channel 2 Mode list box arrow and select either INPUT (analog or digital) or OUTPUT (relay control) for Channel 2.
7 - Analog Sensor Zero area	4-20mA option button	Select the 4-20mA option button to apply the designated sensor reading entered in the Zero Value text box when using a 4-20mA input.
7 - Analog Sensor Zero area	1-5V option button	Select the 1-5V option button to apply the designated sensor reading entered in the Zero Value text box when using a 1-5V input.
7 - Analog Sensor Zero area	Scaled Units option button	Select the Scaled Units option button to scale to an engineering unit equivalent (e.g., 4-20mA = 0-1000 PSI).
7 - Analog Sensor Zero area	Channel A option button	Select the Channel A option button to assign the changed settings to Channel A in a 2-channel device.
7 - Analog Sensor Zero area	Channel B option button	Select the Channel B option button to assign the changed settings to Channel B in a 2-channel device.
7 - Analog Sensor Zero area	Zero Value text box	In the Zero Value text box, enter what the sensor should be reading.
7 - Analog Sensor Zero area	Read Zero Offset button	Click the Read Zero Offset button to force the sensor to use the setting in the Zero Value text box.
7 - Analog Sensor Zero area	Erase Zero Offset button	Click the Erase Zero Offset button to erase the value entered in the Zero Value text box.
8 - Relay Settings area	Comm Failsafe (min) list box	Click the Comm Failsafe (min) list box arrow and select the time to set the outputs to a de-energized state if the link is lost with the Gateway after the set time. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: This setting is used for Remote Shutdown Device.</p> </div>

Edit Configuration window - General Sensor		
Control Area	Control Title	Control Description
8 - Relay Settings area	Message Failsafe (min) list box	<p>Click the Message Failsafe (min) list box arrow and select the time to set the outputs to a de-energized state if messages are lost from the Gateway after the selected time.</p> <div style="border: 1px solid orange; padding: 5px; margin: 10px 0;">  <p>Caution: If a time is selected in the Message Failsafe (min) list box, the time entered must be set higher than the Modbus Coil Write and Analog Output Write frequency of the Modbus master device.</p> </div>
8 - Relay Settings area	Relay 1 Control or Relay 2 Control Energize button	Click the Relay 1 Control or Relay 2 Control Energize button to manually test (energize) the relays.
8 - Relay Settings area	Relay 1 Control or Relay 2 Control De-Energize button	Click the Relay 1 Control or Relay 2 Control De-Energize button to manually test (de-energize) the relays.
9 - HART Configuration area	Scan button	<p>Click the Scan button to scan for the HART ID and show it in the first Polling Address list box so it can be changed later using this same window.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Important!: The HART ID must be set to 1 for the WC20i to communicate with the HART sensor.</p> </div>
9 - HART Configuration area	Polling Address list boxes	Click the second Polling Address list box arrow and select the new HART ID to change the HART sensor to.

13.3. Firmware Updates window

The **Firmware Updates** window is used to access and transfer the update file for the WC45i-GW-485.

Access and Window Description

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Updates** menu, click either **Update Gateway Firmware** or **Update Radio Firmware**.




Figure 56: Updates menu

The **Firmware Updates** window opens.

13.3.1. Update Gateway Firmware menu - Firmware Updates window

Note: By default, the latest firmware file is selected from the update server. When the **Update Gateway Firmware** menu is selected, the WC45i-Gateway searches for the most recent **modbusGW** file to update.




Figure 57: Update Gateway Firmware menu - Firmware Updates window

13.3.2. Update Radio Firmware menu - Firmware Updates window

Note: By default, the latest firmware file is selected from the update server. When the **Update Radio Firmware** menu is selected, the WC45i-Gateway searches for the most recent **appNode** file to update.




Figure 58: Update Radio Firmware menu - Firmware Updates window

Firmware Updates window	
Control Title	Control Description
Current File text box	<p>The Current File text box shows the selected file location of the update file.</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: By default, the latest firmware file is selected from the update server.</p> </div>
Browse button	<p>Click to open the Open dialog box.</p> <p>Use the dialog box to search for and select the update file.</p>
Start Transfer button	<p>Click the Start Transfer button to load the file to the device.</p>

13.4. Gateway Log window

The **Gateway Log** window is used to log events such as reboots, remote Endpoints joining and/or timing out, local RSD control events, remote configuration sessions, firmware updates, etc.

There are two tabs in the window:

- [Gateway Log tab \(on page 74\)](#)
- [Log Statistics tab \(on page 76\)](#)

Access and Window Description

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Tools** menu, click **View Gateway Log**.




Figure 59: WC45i-GW-485 Modbus Gateway > Tools menu > View Gateway Log

The **Gateway Log** window opens.
The **Gateway Log** tab is active.

There are two tabs in the window:

- [Gateway Log tab \(on page 74\)](#)
- [Log Statistics tab \(on page 76\)](#)

13.4.1. Gateway Log tab

Note: The information in this tab is read-only.




Figure 60: Gateway Log window - Gateway Log tab

Gateway Log window - Gateway Log tab		
Control Area	Control Title	Control Description
Gateway Log table	Timestamp column	The Timestamp column shows the date and time of the event.
Gateway Log table	Sequence column	The Sequence column shows the count number assigned to the event in the order it happened.
Gateway Log table	Event Type column	The Event Type column shows the name of the event. Important! FreeWave internal use only.
Gateway Log table	Message column	The Message column shows a description of the Event Type activity. Important! FreeWave internal use only.
	Refresh button	Click the Refresh or Refresh List button to update the information in the table.
	Log Entries list box	Click the Log Entries list box arrow and select how many log entries to view on the Gateway Log tab. Note: The default value is 100.

Gateway Log window - Gateway Log tab		
Control Area	Control Title	Control Description
	Gateway Powered On text box	The Gateway Powered On text box shows how long the Gateway has had continuous power.
	Gateway Uptime text box	The Gateway Uptime text box shows the time the Gateway has been active since the last reboot.
	Last Power Up text box	The Last Power Up text box shows the date and time when the Gateway power supply was started.
	Last Reboot text box	The Last Reboot text box shows the date and time when the Gateway was rebooted.
	Load Log from File button	Click the Load Log from File button to open the Microsoft® Open dialog box with the default location where the .csv file of the log information is saved.
	Save Log to File button	Click the Save Log to File button to open the Microsoft® Save As dialog box with the default location to save the .csv file of the log information in.

13.4.2. Log Statistics tab

The **Log Statistics** tab shows statistics about the log events.



The information in the **Log Statistics** table can be saved as a CSV file to view in a spreadsheet program.

Note: The information in this tab is read-only.
The terms node and Endpoint are used interchangeably in this document.






Figure 61: Gateway Log window - Log Statistics tab

Gateway Log window - Log Statistics tab		
Control Area	Control Title	Control Description
Log Statistics table	Slave ID column	The Slave ID column / text box shows the remote source Endpoint Modbus Slave ID selected in the Settings area of the Device Configuration window.
Log Statistics table	Node Type column	The Node Type column shows the type of Endpoint attached to the WC45i-Gateway.
Log Statistics table	Time Joined column	The Time Joined column shows when the Endpoint was connected to the Gateway.
Log Statistics table	Number of Timeouts column	The Number of Timeouts column shows the number of times the Endpoint has timed out since connected to the Gateway.
Log Statistics table	Last Time Out column	The Last Time Out column shows date and time of the last timeout for the attached Endpoint.

Gateway Log window - Log Statistics tab		
Control Area	Control Title	Control Description
Log Statistics table	RSSI (dbm) column	<p>The RSSI (dbm) column / text box shows the signal strength received from the Endpoint to its neighbor (e.g., a neighbor could be the Gateway if it is not hopping).</p> <div style="border: 1px solid gray; padding: 5px; background-color: #e6f2ff;"> <p>Example: The RSSI is adjusted so if a 500mW device is communicating to a 40mW device the RSSI is shown as being equal in both directions at the lower signal strength.</p> </div> <p>Notes</p> <ul style="list-style-type: none"> • All communications are bi-directional so messages are needed in both directions for communications. • The RSSI and TTL values are color coded (green, yellow, orange, red) to indicate the relative link quality of an Endpoint. Red=Bad link, Yellow=OK link, Green=Good link.
Log Statistics table	Remote Configurations column	The Remote Configurations column shows the total number of times the device has been configured remotely.
Log Statistics table	Supply Voltage (mV) column	The Supply Voltage (mV) column shows the last reported supply voltage to the Endpoint from the battery or solar panel.
	Refresh button	Click the Refresh or Refresh List button to update the information in the table.

Gateway Log window - Log Statistics tab		
Control Area	Control Title	Control Description
	Average timeout / week text box	<p>The Average timeout / week text box shows the average number of timeouts in a week for an Endpoint since a reboot.</p> <p>Notes</p> <ul style="list-style-type: none"> • A timeout is when an Endpoint's TTL, shown in the Device Configuration window (on page 57), goes to 0 (zero) and the data is deleted from the Gateway. • This number does not reset. • This time (in minutes) = the Checkin Interval list box selection * 5 + 2 minutes. <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;">  <p>The bar to the left of the text provides a visual depiction of the average timeout (Red=Bad, Yellow=OK, Green=Good).</p> </div> <div style="border: 1px solid gray; padding: 5px; margin-top: 10px; background-color: #e0e0e0;"> <p>Example: If 1 minute is selected in the Checkin Interval list box AND the Gateway does NOT get an update within 7 minutes ($1*5+2=7$), it will timeout the data and increment the timeout count by 1.</p> </div>
	Average timeout / day text box	<p>The Average timeout / day text box shows the average number of timeouts in a day for an Endpoint since a reboot.</p> <ul style="list-style-type: none"> • A timeout is when an Endpoint's TTL, shown in the Device Configuration window (on page 57), goes to 0 (zero) and the data is deleted from the Gateway. • This number does not reset. • This time (in minutes) = the Checkin Interval list box selection * 5 + 2 minutes. <div style="border: 1px solid gray; padding: 5px; margin-top: 10px;">  <p>The bar to the left of the text provides a visual depiction of the average timeout (Red=Bad, Yellow=OK, Green=Good).</p> </div> <div style="border: 1px solid gray; padding: 5px; margin-top: 10px; background-color: #e0e0e0;"> <p>Example: If 1 minute is selected in the Checkin Interval list box AND the Gateway does NOT get an update within 7 minutes ($1*5+2=7$), it will timeout the data and increment the timeout count by 1.</p> </div>
	Gateway Reboots text box	The Gateway Reboots text box shows the number of times the Gateway has rebooted since it was activated.
	Gateway Uptime text box	The Gateway Uptime text box shows the time the Gateway has been active since the last reboot.

Gateway Log window - Log Statistics tab		
Control Area	Control Title	Control Description
	Save Report to File button	Click the Save Report to File button to open the Microsoft® Save As dialog box with the default location to save the CSV version of the log file in.

13.5. (RegisterView) Slave 1 window

The **(RegisterView) Slave 1** window is used to view additional details about the selected Endpoint, including the register data from the remote Endpoint.

Access and Window Description

1. Verify the [Configuration \(on page 24\)](#) procedure is completed.
2. Double-click one of the Endpoint rows in the **Modbus Slaves Reporting** table. The **(RegisterView) Slave 1** window opens.




Figure 62: (RegisterView) Slave 1 window

(RegisterView) Slave 1 window	
Control Title	Control Description
Update Register Values button	Click the Update Register Values button to update the information in the table.
Load Tags button	Click the Load Tags button to open the Microsoft® Open dialog box with the default location where the .regtag version of the log files are saved.
Save Tags button	Click the Save Tags button to open the Microsoft® Save As dialog box with the default location to save the .regtag version of the log file in.
Slave ID text box	<p>The Slave ID column / text box shows the remote source Endpoint Modbus Slave ID selected in the Settings area of the Device Configuration window.</p> <p>Note: This information is read-only.</p>
Node Name text box	<p>The Node Name column / text box shows the name assigned to the Endpoint in the Settings area of the Device Configuration window.</p> <p>Note: This information is read-only.</p>
Node Address text box	<p>The Node Address text box shows the unique radio address assigned to the radio.</p> <p>Note: This information is read-only.</p>
Battery Voltage (V) text box	<p>The Battery Voltage (V) text box shows the battery voltage of the Endpoint.</p> <p>Note: This information is read-only.</p>
Route text box	<p>The Route text box shows the route the packet used to get to the Gateway.</p> <p>Example: Figure 62 shows one hop and the RSSI of the hop.</p> <p>Note: This information is read-only.</p>

(RegisterView) Slave 1 window	
Control Title	Control Description
RSSI (dbm) text box	<p>The RSSI (dbm) column / text box shows the signal strength received from the Endpoint to its neighbor (e.g., a neighbor could be the Gateway if it is not hopping).</p> <p>Note: This information is read-only.</p> <p>Example: The RSSI is adjusted so if a 500mW device is communicating to a 40mW device the RSSI is shown as being equal in both directions at the lower signal strength.</p> <p>Note: All communications are bi-directional so messages are needed in both directions for communications.</p>
Data Type list box column	<p>The Data Type list box column shows the data type for the identified Endpoint and its data register.</p> <p>Notes</p> <ul style="list-style-type: none"> • When the Endpoint is automatically identified by the Gateway, the Data Type list box column is read-only and cannot be changed. • If the Data Type is NOT known, click the Data Type list box arrow and select the data format for the Modbus register. • If the Apply Default Register Map check box is cleared, the Data Type options are available. <p>The options are:</p> <ul style="list-style-type: none"> • 16bit UINT • 32bit UINT • 32bit INT • 32bit FLOAT • 32bit UINT (Enron) • 32bit INT (Enron) • 32bit FLOAT (Enron) <p>Important!: The Data Type text box cannot be changed when it is identified by the Gateway.</p>
Register Address column	The Register Address column shows the register address set by the Endpoint that is sending the data to the Gateway.
Register Value column	The Register Value column shows data that the Endpoint is sending in.
Description column	The Description column shows information describing the data at this Register Address .

(RegisterView) Slave 1 window	
Control Title	Control Description
Apply Default Register Map check box	Click the Apply Default Register Map check box to have the Gateway auto-detect the Endpoint register information. Clear the check box to manually select the Endpoint register information. Note: By default, when the Gateway recognizes the connected Endpoint type, the Apply Default Register Map check box is selected.
Display Address in HEX check box	Click the Display Address in HEX check box to view the Register Address column information as hexadecimal values.
Display Value in HEX check box	Click the Display Value in HEX check box to view the Register Value column information as hexadecimal values.

13.6. Remote Shutdown Settings window

The **Remote Shutdown Settings** window is used to control output relays on the WC40i-MB-RSD Modbus Endpoint or WC40i-COUNT.

Access and Window Description

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Settings** menu, click **Remote Shutdown Settings**.




Figure 63: WC45i-GW-485 Modbus Gateway Settings menu > Remote Shutdown Settings

The **Remote Shutdown Settings** window has these sections:

- [Source Node \(Endpoint\) area \(on page 86\)](#)
- [Relay Control Logic Section \(on page 88\)](#)
- [Destination Counter / RSD Stick Section \(on page 90\)](#)




Figure 64: Remote Shutdown Settings window

Remote Shutdown Settings window	
Control Title	Control Description
Update button	Click the Update button to refresh the information in the Current Register Value column and the Current Relay State column.

Remote Shutdown Settings window	
Control Title	Control Description
Remote Shutdown Settings table	See these sections for detailed descriptions: <ul style="list-style-type: none"> • Source Node (Endpoint) area (on page 86) • Relay Control Logic Section (on page 88) • Destination Counter / RSD Stick Section (on page 90)
Read Remote Shutdown Settings from Gateway button	Click the Read Remote Shutdown Settings from Gateway button to retrieve the stored settings from the WC45i-Gateway.
Write Remote Shutdown Settings to Gateway button	Click the Write Remote Shutdown Settings to Gateway button to store the settings in the WC45i-Gateway.
Failsafe Enabled check box	Click the Failsafe Enabled check box to require ALL rules to have valid data for the relay to be energized. <ul style="list-style-type: none"> • If one or more of the Endpoints time-out or does not exist, the relay is de-energized. • If this option is NOT selected, then an Endpoint that is not installed or fails to check in is ignored and the relay is energized using logic only from the units that are active.
Latch De-Energized check box	Click the Latch De-Energized check box so the rules may only de-energize the relay. <ul style="list-style-type: none"> • For the relay to be energized again, a Modbus write from a PLC to the Gateway for the destination WC40i-MB-RSD or WC40i-COUNT relay must occur. • This is useful if manual intervention is required before the relay is energized after an event. • In 10, a Modbus coil write to Slave ID 5 relay channel 1 (which is register 1) is required to energize the relay. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: See the WC40i-COUNT Counter Endpoint or WC40i-MB-RSD Modbus Endpoint User Manual for a detailed register map.</p> </div>
Save to File button	Click the Save to File button to open the Microsoft® Save As dialog box with the default location to save the .rsd file in.
Load from File button	Click the Load from File button to open the Microsoft® Open dialog box with the default location to load the .rsd file from.
Clear Remote Shutdown Table button	Click the Clear Remote Shutdown Table button to clear the table of custom configuration settings and return to the default configuration information.

13.6.1. Source Node (Endpoint) area

The **Source Node (Endpoint)** area is used to select the source register for the logic rule.

Source Node				
Slave ID	Node Type	Register Address	Register Type	Current Register Value
2	WC20i-Anal...	3003-Scaled	32bit FLOAT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown
0	None	0	16bit UINT	Unknown

Figure 65: Source Node (Endpoint) area

Source Node (Endpoint) area - WC45i-GW-485	
Column	Description
Slave ID column	<p>The Slave ID column / text box shows the remote source Endpoint Modbus Slave ID selected in the Settings area of the Device Configuration window.</p> <p>Note: This information is read-only.</p>
Node Type column / list box	<p>Click the Node Type list box arrow and select the type of remote Endpoint.</p> <ul style="list-style-type: none"> The list box contains a list of the standard WAVECONTACT remote Endpoints. <p>Note: Select Custom for manual data entry.</p>
Register Address column / list box	<p>Click the Register Address list box arrow and select the register address for the data to use for the logic.</p> <p>Important!: If Custom was select in the Node Type column / list box, click the Register Type list box arrow and select the correct data type.</p>

Source Node (Endpoint) area - WC45i-GW-485	
Column	Description
Register Type column / list box	<p>If Custom was select in the Node Type column / list box, click the Register Type list box arrow and select the correct data type.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: The correct Register Type is automatically selected unless a Custom Node Type is used.</p> </div>
Current Register Value column	<p>The Current Register Value column shows the value of the selected source data register.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: Click the Update button to refresh the information in the Current Register Value column and the Current Relay State column.</p> </div>

13.6.2. Relay Control Logic Section

The **Relay Control Logic Section** is used to set the trigger thresholds for the selected source data register.

Relay Details

The relays used on the Output Module are SPDT (NO/NC) relays and have these ratings:


Output Module Relay - WC45i-GW-485	
Relay	Rating
30 VDC	2 A
125 VAC	0.5 A
10 ⁸	Operations (life)

Notes

- The relays have **Normally Open (NO)** and **Normally Closed (NC)** contacts.
- The **Normal** state of the relay is the de-energized state.
 - This state should be used to set the controlled system (pump, motor, etc.) in the safe or off state.

Relay Control Logic				
Run System (Energize Relay) when...	Value	Shutdown System (De-energize Relay) when...	Value	Number of Readings
Less than	4000	Greater than	4100	3
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1
Greater than	0	Less than	0	1

Figure 66: Relay Control Logic Section

Relay Control Logic Section - WC45i-GW-485	
Columns	Description
Run System (Energize Relay) column / list box	Click the Run System (Energize Relay) list box arrow and select the logic operand to use for the energize logic evaluation.
Value column / text box	In the Value column / text box, enter the value that the relay is energized at. Note: The Energized state is the normal operating state of the relay.
Shutdown System (De-Energize Relay) column / list box	Click the Shutdown System (De-Energize Relay) list box arrow and select the logic operand to use for the de-energize logic evaluation. Important! By default, this selection is automatically the opposite of the selection for the Run System (Energize Relay) column. Note: The de-energized state is the SAFE state of the relay.
Value column / text box	In the Value column / text box, enter the value that the relay is de-energized at. Note: The de-energized state is the SAFE state of the relay.
Number of Readings column / list box	Click the Number of Readings list box arrow and select the number of check-in packets that must be received in a row that are above (or below) the logic threshold for the de-energize condition.  This is useful so that a single reading does not cause a shut-down of the Endpoint. <ul style="list-style-type: none"> • The default is 1 where each check-in will cause the rule to be evaluated and acted on. • A single reading that satisfies the run system (energize) condition will cause the relay to energize.

13.6.3. Destination Counter / RSD Stick Section

Destination Counter/RSD Stick		
Slave ID	Relay Channel	Current Relay State (readonly)
25	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown
0	1	Unknown

Figure 67: Destination Counter / RSD Stick Section

Destination Counter / RSD Stick Section - WC45i-GW-485	
Column	Description
Slave ID column	<ul style="list-style-type: none"> This is the Slave ID of the destination WC40i-COUNT. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: This information is read-only.</p> </div>
Relay Channel column / list box	Click the Relay Channel list box arrow and select the relay channel to switch.
Current Relay State column	<p>The Current Relay State column shows the last value of the relay as reported to the Gateway.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: Click the Update button to refresh the information in the Current Register Value column and the Current Relay State column.</p> </div>

13.7. Slave Register Remapping window

The Gateway allows any of the remote register data to be remapped to a single block of registers available at the Gateway's Slave ID.

Note: The default is 247.

- This is useful for collecting a subset of register data from multiple Endpoints and making it readable in a single block of registers.
- A maximum of 750 registers can be remapped to the Gateway's Slave ID starting at register 5000.

The **Slave Register Remapping** window is used to remap the remote register data to a single block of registers available at the Gateway's Slave ID.

Access and Window Description

1. Open the [Device Configuration window \(on page 57\)](#).
2. On the **Settings** menu, click **Slave Register Remapping**.




Figure 68: Settings menu > Slave Register Remapping

The **Slave Register Remapping** window opens.




Figure 69: Slave Register Remapping window

Slave Register Remapping window		
Control Area	Control Title	Control Description
	Refresh button	Click the Refresh or Refresh List button to update the information in the table.
Slave Register Remapping table	Remapped Address column	The Remapped Address column shows the Modbus address for the remapped register.
Slave Register Remapping table	Slave ID column	The Slave ID column / text box shows the remote source Endpoint Modbus Slave ID selected in the Settings area of the Device Configuration window.
Slave Register Remapping table	Register Address column	In the Register Address column text box, enter the register address to map to each Gateway register. <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Note: The Node Name, Data Type, Register Value, and Description columns are automatically filled in by the Gateway once the mapping is written to the Gateway.</p> </div>
Slave Register Remapping table	Node Name column	The Node Name column / text box shows the name assigned to the Endpoint in the Settings area of the Device Configuration window.

Slave Register Remapping window		
Control Area	Control Title	Control Description
Slave Register Remapping table	Data Type list box column	<p>The Data Type list box column shows the data type for the identified Endpoint and its data register.</p> <p>Notes</p> <ul style="list-style-type: none"> When the Data Type is automatically identified by the Gateway, the Data Type list box column is read-only and cannot be changed. If the Data Type is NOT known, click the Data Type list box arrow and select the data format for the Modbus register. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Important! The Data Type text box cannot be changed when it is identified by the Gateway.</p> </div>
Slave Register Remapping table	Register Value column	The Register Value column shows data that the Endpoint is sending in.
Slave Register Remapping table	Description column	The Description column shows information describing the data at this Register Address .
	Read Mapping from Gateway button	Click the Read Mapping to Gateway button to read the current registers.
	Write Mapping from Gateway button	Click the Write Mapping to Gateway button to remap the registers.
	Clear Table button	Click the Clear Table button to reset any changes made in the window to its defaults.
	Clear Gateway button	Click the Clear Gateway button to clear any settings written to the Gateway.
	Save to File button	Click the Save to File button to open the Microsoft® Save As dialog box with the default location to save the .remap file.
	Load from File button	Click the Load from File button to open the Microsoft® Open dialog box with the default location to load the .remap file from.
	Export to CSV button	Click the Export to CSV button to open the Microsoft® Save As dialog box with the default location to save the .csv file in.
Display area	Apply Default Register Map check box	<div style="border: 1px solid black; padding: 5px;"> <p>Note: By default, when the Gateway recognizes the connected Endpoint type, the Apply Default Register Map check box is selected.</p> </div>

Slave Register Remapping window		
Control Area	Control Title	Control Description
Display area	Show Register Addresses in HEX check box	Click the Show Register Addresses in HEX check box to view the Register Address column information as hexadecimal values.
Display area	Show Data Values in HEX check box	Click the Show Data Values in HEX check box to view the Register Value column information as hexadecimal values.
Display area	Use Extended Slave ID (2-bytes) check box	Click the Use Extended Slave ID (2-bytes) check box to activate the Use Extended Slave ID (2-bytes) text box. <ul style="list-style-type: none"> When this check box is NOT selected, the Modbus address of the Gateway is 8 bits in length. When with the check box selected, the Modbus address of the Gateway is 16 bits in length and equal to the value entered in the Use Extended Slave ID (2-bytes) text box.
Display area	Use Extended Slave ID (2-bytes) text box	In the Use Extended Slave ID (2-bytes) text box, enter any number from 0 to 4095 to designate the 16 bit Modbus address of the Gateway.
Display area	Set button	Click the Set button to save the information.
Fail Mode area	Fail Mode with High Value option button	Select the Fail Mode with High Value option button to return a Modbus value of 65535 when polling of the end device fails.
Fail Mode area	Fail with Last Value (else High) option button	Select the Fail with Last Value (else High) option button to return the last value polled from the end device if there was never any data for that register or if the Gateway reboots or is re-powered. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: If no successful poll has yet occurred, returns 65535.</p> </div>
Fail Mode area	Fail Mode with Low Value option button	Select the Fail Mode with Low Value option button to return a Modbus value of 0 (zero) when polling of the end device fails.
Fail Mode area	Fail with Last Value (else Low) option button	Select the Fail with Last Value (else Low) option button to return the last value polled form the end device if there was never any data for that register or if the Gateway reboots or is re-powered. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Note: If no successful poll has yet occurred, returns 0 (zero).</p> </div>

14. WAVECONTACT Network Frequencies

The frequencies used by the WAVECONTACT network vary depending on the **Radio Network** and **Radio Network Group** selected in the [Device Configuration window \(on page 57\)](#).

Example: Using the [Radio Network Group Selection: 0, 1, 2, or 3 \(on page 96\)](#) table, the **Radio Network** and **Radio Network Group** settings of 0 (zero) and 0 (zero) (respectively) uses the frequencies between 908.20 and 918.20.

The **Radio Network** and **Radio Network Group** settings of 0 (zero) and 2 (respectively) uses 905.00 to 915.00.

- [Radio Network Group Selection: 0, 1, 2, or 3 \(on page 96\)](#)
- [Radio Network Group Selection: 4, 5, 6, or 7 \(on page 97\)](#)
- [Radio Network Group Selection: 8, 9, 10, 11 \(on page 98\)](#)
- [Radio Network Group Selection: 12, 13, 14, 15 \(on page 99\)](#)
- [Radio Network Group Selection: 16, 17, 18, or 19 \(on page 100\)](#)
- [Radio Network Group Selection: 20, 21, 22, 23 \(on page 101\)](#)
- [Radio Network Group Selection: 28 or 29 \(on page 103\)](#)

14.1. Radio Network Group Selection: 0, 1, 2, or 3

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 0, 1, 2, or 3.

Radio Network selection	Radio Network Group selection: 0 or 1	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 2 or 3	Low Frequency	High Frequency
0	0	908.20	918.20	0	2	905.00	915.00
1	0	908.40	918.40	1	2	905.20	915.20
2	0	908.60	918.60	2	2	905.40	915.40
3	0	908.80	918.80	3	2	905.60	915.60
4	0	909.00	919.00	4	2	905.80	915.80
5	0	909.20	919.20	5	2	906.00	916.00
6	0	909.40	919.40	6	2	906.20	916.20
7	0	909.60	919.60	7	2	906.40	916.40
0	1	909.80	919.80	0	3	906.60	916.60
1	1	910.00	920.00	1	3	906.80	916.80
2	1	910.20	920.20	2	3	907.00	917.00
3	1	910.40	920.40	3	3	907.20	917.20
4	1	910.60	920.60	4	3	907.40	917.40
5	1	910.80	920.80	5	3	907.60	917.60
6	1	911.00	921.00	6	3	907.80	917.80
7	1	911.20	921.20	7	3	908.00	918.00

14.2. Radio Network Group Selection: 4, 5, 6, or 7

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 4, 5, 6, or 7.

Radio Network selection	Radio Network Group selection: 4 or 5	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 6 or 7	Low Frequency	High Frequency
0	4	908.20	918.20	0	6	905.00	915.00
1	4	908.40	918.40	1	6	905.20	915.20
2	4	908.60	918.60	2	6	905.40	915.40
3	4	908.80	918.80	3	6	905.60	915.60
4	4	909.00	919.00	4	6	905.80	915.80
5	4	909.20	919.20	5	6	906.00	916.00
6	4	909.40	919.40	6	6	906.20	916.20
7	4	909.60	919.60	7	6	906.40	916.40
0	5	909.80	919.80	0	7	906.60	916.60
1	5	910.00	920.00	1	7	906.80	916.80
2	5	910.20	920.20	2	7	907.00	917.00
3	5	910.40	920.40	3	7	907.20	917.20
4	5	910.60	920.60	4	7	907.40	917.40
5	5	910.80	920.80	5	7	907.60	917.60
6	5	911.00	921.00	6	7	907.80	917.80
7	5	911.20	921.20	7	7	908.00	918.00

14.3. Radio Network Group Selection: 8, 9, 10, 11

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 8, 9, 10, or 11.

Radio Network selection	Radio Network Group selection: 8 or 9	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 10 or 11	Low Frequency	High Frequency
0	8	908.20	918.20	0	10	905.00	915.00
1	8	908.40	918.40	1	10	905.20	915.20
2	8	908.60	918.60	2	10	905.40	915.40
3	8	908.80	918.80	3	10	905.60	915.60
4	8	909.00	919.00	4	10	905.80	915.80
5	8	909.20	919.20	5	10	906.00	916.00
6	8	909.40	919.40	6	10	906.20	916.20
7	8	909.60	919.60	7	10	906.40	916.40
0	9	909.80	919.80	0	11	906.60	916.60
1	9	910.00	920.00	1	11	906.80	916.80
2	9	910.20	920.20	2	11	907.00	917.00
3	9	910.40	920.40	3	11	907.20	917.20
4	9	910.60	920.60	4	11	907.40	917.40
5	9	910.80	920.80	5	11	907.60	917.60
6	9	911.00	921.00	6	11	907.80	917.80
7	9	911.20	921.20	7	11	908.00	918.00

14.4. Radio Network Group Selection: 12, 13, 14, 15

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 12, 13, 14, or 15.

Radio Network selection	Radio Network Group selection: 12 or 13	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 14 or 15	Low Frequency	High Frequency
0	12	908.20	918.20	0	14	905.00	915.00
1	12	908.40	918.40	1	14	905.20	915.20
2	12	908.60	918.60	2	14	905.40	915.40
3	12	908.80	918.80	3	14	905.60	915.60
4	12	909.00	919.00	4	14	905.80	915.80
5	12	909.20	919.20	5	14	906.00	916.00
6	12	909.40	919.40	6	14	906.20	916.20
7	12	909.60	919.60	7	14	906.40	916.40
0	13	909.80	919.80	0	15	906.60	916.60
1	13	910.00	920.00	1	15	906.80	916.80
2	13	910.20	920.20	2	15	907.00	917.00
3	13	910.40	920.40	3	15	907.20	917.20
4	13	910.60	920.60	4	15	907.40	917.40
5	13	910.80	920.80	5	15	907.60	917.60
6	13	911.00	921.00	6	15	907.80	917.80
7	13	911.20	921.20	7	15	908.00	918.00

14.5. Radio Network Group Selection: 16, 17, 18, or 19

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 16, 17, 18, or 19.

Radio Network selection	Radio Network Group selection: 16 or 17	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 18 or 19	Low Frequency	High Frequency
0	16	908.20	918.20	0	18	905.00	915.00
1	16	908.40	918.40	1	18	905.20	915.20
2	16	908.60	918.60	2	18	905.40	915.40
3	16	908.80	918.80	3	18	905.60	915.60
4	16	909.00	919.00	4	18	905.80	915.80
5	16	909.20	919.20	5	18	906.00	916.00
6	16	909.40	919.40	6	18	906.20	916.20
7	16	909.60	919.60	7	18	906.40	916.40
0	17	909.80	919.80	0	19	906.60	916.60
1	17	910.00	920.00	1	19	906.80	916.80
2	17	910.20	920.20	2	19	907.00	917.00
3	17	910.40	920.40	3	19	907.20	917.20
4	17	910.60	920.60	4	19	907.40	917.40
5	17	910.80	920.80	5	19	907.60	917.60
6	17	911.00	921.00	6	19	907.80	917.80
7	17	911.20	921.20	7	19	908.00	918.00

14.6. Radio Network Group Selection: 20, 21, 22, 23

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 20, 21, 22, or 23.

Radio Network selection	Radio Network Group selection: 20 or 21	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 22 or 23	Low Frequency	High Frequency
0	20	908.20	918.20	0	22	905.00	915.00
1	20	908.40	918.40	1	22	905.20	915.20
2	20	908.60	918.60	2	22	905.40	915.40
3	20	908.80	918.80	3	22	905.60	915.60
4	20	909.00	919.00	4	22	905.80	915.80
5	20	909.20	919.20	5	22	906.00	916.00
6	20	909.40	919.40	6	22	906.20	916.20
7	20	909.60	919.60	7	22	906.40	916.40
0	21	909.80	919.80	0	23	906.60	916.60
1	21	910.00	920.00	1	23	906.80	916.80
2	21	910.20	920.20	2	23	907.00	917.00
3	21	910.40	920.40	3	23	907.20	917.20
4	21	910.60	920.60	4	23	907.40	917.40
5	21	910.80	920.80	5	23	907.60	917.60
6	21	911.00	921.00	6	23	907.80	917.80
7	21	911.20	921.20	7	23	908.00	918.00

14.7. Radio Network Group Selection: 24, 25, 26, 27

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 24, 25, 26, or 27.

Radio Network selection	Radio Network Group selection: 24 or 25	Low Frequency	High Frequency	Radio Network selection	Radio Network Group selection: 26 or 27	Low Frequency	High Frequency
0	24	908.20	918.20	0	26	905.00	915.00
1	24	908.40	918.40	1	26	905.20	915.20
2	24	908.60	918.60	2	26	905.40	915.40
3	24	908.80	918.80	3	26	905.60	915.60
4	24	909.00	919.00	4	26	905.80	915.80
5	24	909.20	919.20	5	26	906.00	916.00
6	24	909.40	919.40	6	26	906.20	916.20
7	24	909.60	919.60	7	26	906.40	916.40
0	25	909.80	919.80	0	27	906.60	916.60
1	25	910.00	920.00	1	27	906.80	916.80
2	25	910.20	920.20	2	27	907.00	917.00
3	25	910.40	920.40	3	27	907.20	917.20
4	25	910.60	920.60	4	27	907.40	917.40
5	25	910.80	920.80	5	27	907.60	917.60
6	25	911.00	921.00	6	27	907.80	917.80
7	25	911.20	921.20	7	27	908.00	918.00

14.8. Radio Network Group Selection: 28 or 29

In the [Device Configuration window \(on page 57\)](#), these are the **High** and **Low Frequencies** when the **Radio Network Group** list box selection is 28 or 29.

Radio Network selection	Radio Network Group selection: 28 or 29	Low Frequency	High Frequency
0	28	908.20	918.20
1	28	908.40	918.40
2	28	908.60	918.60
3	28	908.80	918.80
4	28	909.00	919.00
5	28	909.20	919.20
6	28	909.40	919.40
7	28	909.60	919.60
0	29	909.80	919.80
1	29	910.00	920.00
2	29	910.20	920.20
3	29	910.40	920.40
4	29	910.60	920.60
5	29	910.80	920.80
6	29	911.00	921.00
7	29	911.20	921.20

Appendix A: Technical Specifications

Technical Specification: WC45i-GW-485 Modbus Gateway	
Specification	Description
Transmitter	
Frequency	902-928 MHz license-free ISM band compliant with FCC Part 15
Range	3 miles or more, depending on placement
Networks	Up to 64 separate networks receiver
Sensitivity	-105dB
Interfaces	
Data Interface	RS-485 Modbus RTU, or Modbus-TCP, RS 232 for configuration. <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p>Note: All readings are converted to Modbus registers and stored in the Gateway.</p> </div>
Internal Diagnostics	<ul style="list-style-type: none"> • Line voltage • Signal Strength • Error conditions • Internal event logging
Power Requirements	
Power	+6 to +36VDC
Radio Power	500 mW
General Information	
Operating Temperature	-40°C to 85°C

Technical Specification: WC45i-GW-485 Modbus Gateway	
Specification	Description
Humidity	0% - 100% condensing
Antenna Type	Omnidirectional
Antenna Gain	5dB
Weight	2.4 lbs
Enclosure	Weather-tight, integrated electronics and antenna, NEMA 3R
Safety Rating	Non-incendive, Class 1 Division 2 Groups C and D, T5

Appendix B: Connection Troubleshooting

Verify the connection between the Gateway and Endpoint:

- Check the LEDs on the Endpoint.
 - If LEDs don't indicate linked, double check radio settings.
 - See [LEDs \(on page 107\)](#).
- If the Endpoint is linking, use the 4-pin to USB programming cable to connect to Gateway and examine the Endpoints reporting to that Gateway.
- If the Endpoints are reporting in, double check that the Modbus IDs and registers are correct in the Modbus master.

Appendix C: LEDs

The WC45i-GW-485 has one LED available for field diagnostics.

Status LEDs	Description
Slow Flash (3 second pause)	System is running and in communication with radio network.
Fast Flash (0.5 second pause)	System is running but no network found.
Solid On	System Fault needs service or rescue bootload.

Appendix D: Available Accessories

These accessories are available from FreeWave for the WAVECONTACT products.

Available Accessories	
FreeWave Part #	Description
WC-USB-DB9	USB to Serial DB9 programming cable
WC45-Whip	Whip Antenna Suitable for use in fiberglass or plastic enclosure with direct mount to DIN mounted card.
WC45-PM	Panel Mount Antenna Mount outside of an enclosure.

Appendix E: FreeWave Legal Information

Export Notification

FreeWave Technologies, Inc. products may be subject to control by the Export Administration Regulations (EAR) and/or the International Traffic in Arms Regulations (ITAR). Export, re-export, or transfer of these products without required authorization from the U.S. Department of Commerce, Bureau of Industry and Security, or the U.S. Department of State, Directorate of Defense Trade Controls, as applicable, is prohibited. Any party exporting, re-exporting, or transferring FreeWave products is responsible for obtaining all necessary U.S. government authorizations required to ensure compliance with these and other applicable U.S. laws. Consult with your legal counsel for further guidance.

FCC Notifications

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference and 2) this device must accept any interference received, including interference that may cause undesired operation.

The content of this guide covers FreeWave Technologies, Inc. models sold under FCC ID: W8V-M655.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of these measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Notification of Power Warning

The WC45i-GW-485 Modbus Gateway covered in this document has a maximum transmitted output power of +14dBm.

The antennas used MUST provide a separation distance of at least 20 cm from all persons and MUST NOT be co-located or operate in conjunction with any other antenna or transmitter.

Important!: This label MUST BE visible when the WAVECONTACT product is installed.



WC45i-GW-ETL-FCC-FC C1D2 Label

IC Notifications

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a maximum (or lesser) gain approved for this transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.r.i.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Ce dispositif est conforme aux normes permis-exemptes du Canada RSS d'industrie. L'opération est sujette aux deux conditions suivantes : (1) ce dispositif peut ne pas causer l'interférence, et (2) ce dispositif doit accepter n'importe quelle interférence, y compris l'interférence qui peut causer le fonctionnement peu désiré du dispositif.

Restricted Rights

Any product names mentioned in this manual may be trademarks or registered trademarks of their respective companies and are hereby acknowledged.

This manual is only for use by purchasers and other authorized users of FreeWave products.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, or for any purpose without the express written permission of FreeWave Technologies, Inc. FreeWave reserves the right to make changes to this manual without notice. FreeWave assumes no responsibility or liability for the use of this manual or the infringement of any copyright or other proprietary right.

Hazardous Location Certification



Warning! EXPLOSION HAZARD. DO NOT REMOVE OR REPLACE COMPONENTS UNLESS POWER HAS BEEN DISCONNECTED OR THE AREA IS FREE OF IGNITIBLE CONCENTRATIONS.
AVERTISSEMENT : RISQUE D'EXPLOSION. NE PAS RETIRER OU REMPLACER LES COMPOSANTS QUE L'ALIMENTATION EST DÉBRANCHÉ OU ZONE EST LIBRE DE CONCENTRATIONS IGNITIBLE.



Warning! EXPLOSION HAZARD Substitution of components may impair suitability for Class I, Division 2.
AVERTISSEMENT - RISQUE D'EXPLOSION. La substitution de composants peut rendre ce matériel inacceptable pour les emplacements de classe I, division 2.



Warning! EXPLOSION HAZARD Do not disconnect while circuit is live unless area is known to be nonhazardous.
AVERTISSEMENT - RISQUE D'EXPLOSION. Ne débranchez pas lorsque le circuit est en direct , sauf si la zone est connue pour être nonhazardous.



Warning! The Wireless IO Module must be installed in a suitable enclosure for intended environment.
AVERTISSEMENT - Le module IO sans fil doit être installé dans une enceinte appropriée pour l'environnement prévu.



Warning! All wiring methods must be in accordance with the NEC.
AVERTISSEMENT - Toutes les méthodes de Essorez doivent être en conformité avec la NEC.

...
FREEWAVE