

WaveContact Series

Accessories



Batteries

Class I, Division 1 , intrinsically safe, suitable for replacement in hazardous areas.



WC-BAT-1D-IS

Replacement battery for WC30i-PSI and WC30i-TZ.



WC-BAT-3D-IS

Replacement battery for WC20i Modular Endpoints.



WC-BAT-3AA-IS

Replacement battery for WC30i-AXIS.

Connection Cables



WC-USB-4PIN Cable

4-pin-to-USB Interface cable to connect from board-mounted 4-pin header to USB computer port for configuration.

Use with WC20i, WC30i, WC40i-MultiIO



WC-USB-DB9 Cable

USB to Serial DB9 Interface cable for the best plug-and-play performance with FreeWave products.

Use with WC25i, WC40i-RSD, WC45i-P, WC45i-AN, and WC45i-GW-DIN; Use in conjunction with WC45i-BBL for WC45i-GW, WC40i-MB, and WC40i-Count



WC20i-S-CBL10 Cable

10 foot extension cable for solar module.

Use with WC20i-Solar

Antennas

WC20i-Solar



WC-ANT-WHIP Antenna

Use in fiberglass or plastic enclosure with direct mount to DIN mounted card.
Use with WC45i-GW-DIN or WC25i-WL



WC-ANT-PM Antenna

Panel Mount antenna to mount outside of an enclosure.
Use with WC45i-GW-DIN or WC25i-WL



WC20i-Solar Kit

Class I, Division 1 intrinsically safe solar kit for powering WC20i Modular Endpoints. Includes 4 W panel, 9 AH battery, and necessary cabling.
Use with any WC20i-xx-S. Included as part of WC20i-xx-Solar

Mounting Kits

Allows for easy mounting of WC20i Modular Endpoints and their solar kits to common tank level transmitters.



WC20i-B-YOKO

Mounting kit for WC20i Solar Kit—Yokogawa EJA Series.



WC20i-B-R5300

Mounting kit for WC20i Solar Kit—Rosemount 5300.



WC20i-BKT-VEGA

Mounting kit for WC20i Solar Kit—Vega Single Chamber Radar.